

Chapter 32

JUNOScope Main Window

This chapter describes the contents of the JUNOScope software main window.

JUNOScope Window Reference

Figure 12 defines the major areas of the JUNOScope main window.

Figure 12: JUNOScope Main Window




Table 43 describes the parts of the JUNOScope main window.

Table 43: Parts of the JUNOScope Main Window

Part	Description
Header	Includes the following items: <ul style="list-style-type: none"> ■ Juniper Networks logo—Click to go to the Juniper Networks Web site, www.juniper.net. ■ JUNOScope—Shows the name of this application. ■ Home—Click to go to the JUNOScope main window. ■ About—Displays the JUNOScope software release and copyright information. ■ Logout—Closes JUNOScope and displays the Login dialog box. ■ Logged in as: < <i>username</i> > —Displays the username used to log in to JUNOScope.
Task tabs	Display the menu of JUNOScope main commands. Gray tabs are main application tasks that interact with routers or router data. White tabs indicate tasks for administering JUNOScope. Click a task tab to view its contents. <ul style="list-style-type: none"> ■ Looking Glass—Lets you display current operational information for a device, including device chassis, system software, interfaces, and routing protocols. ■ Configuration—Lets you view and edit the device configuration. Additionally, you can archive, compare, display, or restore selected device configurations. ■ Inventory Management—Scans selected devices for hardware and software installed and displays reports of the stored records. ■ Monitor—Lets you view scheduled and pending operations and the status of completed operations. ■ Settings—Lets you view and modify JUNOScope settings to manage devices.
Commands	Indicate the main JUNOScope commands (see the Task tabs section of this table for command descriptions). Click a command to view its submenu of commands.



NOTE: If you click the Reload or Refresh button in your Web browser while using the JUNOScope software, the browser displays the default home page instead of reloading or refreshing the currently displayed JUNOScope main window. Use the Home link in the JUNOScope main window instead to refresh.