

Installing the NMC-RX Provisioning Service

You can install the NMC-RX Provisioning Service Package by launching one of the NMC-RX Element Management System install sets. For instruction on which install set to use and how to install the NMC-RX Provisioning Service Package, see *NMC-RX User Guide, Vol. 1*.

