

## Stateful Firewall for JSF



---

Published: 2012-07-02

Juniper Networks, Inc.  
1194 North Mathilda Avenue  
Sunnyvale, California 94089  
USA  
408-745-2000  
www.juniper.net

This product includes the Envoy SNMP Engine, developed by Epilogue Technology, an Integrated Systems Company. Copyright © 1986-1997, Epilogue Technology Corporation. All rights reserved. This program and its documentation were developed at private expense, and no part of them is in the public domain.

This product includes memory allocation software developed by Mark Moraes, copyright © 1988, 1989, 1993, University of Toronto.

This product includes FreeBSD software developed by the University of California, Berkeley, and its contributors. All of the documentation and software included in the 4.4BSD and 4.4BSD-Lite Releases is copyrighted by the Regents of the University of California. Copyright © 1979, 1980, 1983, 1986, 1988, 1989, 1991, 1992, 1993, 1994. The Regents of the University of California. All rights reserved.

GateD software copyright © 1995, the Regents of the University. All rights reserved. Gate Daemon was originated and developed through release 3.0 by Cornell University and its collaborators. Gated is based on Kirton's EGP, UC Berkeley's routing daemon (routed), and DCN's HELLO routing protocol. Development of Gated has been supported in part by the National Science Foundation. Portions of the GateD software copyright © 1988, Regents of the University of California. All rights reserved. Portions of the GateD software copyright © 1991, D. L. S. Associates.

This product includes software developed by Maker Communications, Inc., copyright © 1996, 1997, Maker Communications, Inc.

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Products made or sold by Juniper Networks or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.

*Stateful Firewall for JSF*  
Copyright © 2012, Juniper Networks, Inc.  
All rights reserved.

The information in this document is current as of the date on the title page.

#### YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

#### END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <http://www.juniper.net/support/eula.html>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

# Table of Contents

	About the Documentation . . . . .	vii
	Documentation and Release Notes . . . . .	vii
	Supported Platforms . . . . .	vii
	Using the Examples in This Manual . . . . .	vii
	Merging a Full Example . . . . .	viii
	Merging a Snippet . . . . .	viii
	Documentation Conventions . . . . .	ix
	Documentation Feedback . . . . .	xi
	Requesting Technical Support . . . . .	xi
	Self-Help Online Tools and Resources . . . . .	xi
	Opening a Case with JTAC . . . . .	xii
<b>Part 1</b>	<b>Overview</b>	
<b>Chapter 1</b>	<b>Stateful Firewall . . . . .</b>	<b>3</b>
	Stateful Firewall Overview for JSF . . . . .	3
	Stateful Firewall Support for Application Protocols . . . . .	4
<b>Part 2</b>	<b>Configuration</b>	
<b>Chapter 2</b>	<b>Configuration Tasks . . . . .</b>	<b>7</b>
	Configuring Stateful Firewall Rules for JSF . . . . .	7
	Configuring Match Direction for Stateful Firewall Rules . . . . .	8
	Configuring Match Conditions in Stateful Firewall Rules . . . . .	8
	Configuring Actions in Stateful Firewall Rules . . . . .	9
	Configuring Stateful Firewall Rule Sets for JSF . . . . .	10
	Configuring Juniper Service Framework – Stateful Firewall, Rules, and Services Set . . . . .	10
	Configuring the JSF Stateful Firewall Package . . . . .	10
	Configuring the Stateful Firewall Rule . . . . .	12
	Configuring the Services Set for Stateful Firewall . . . . .	13
<b>Chapter 3</b>	<b>Example . . . . .</b>	<b>17</b>
	Examples: Configuring Stateful Firewall Rules for JSF . . . . .	17
<b>Chapter 4</b>	<b>Configuration Statements . . . . .</b>	<b>21</b>
	allow-ip-options . . . . .	21
	application-sets . . . . .	22
	applications . . . . .	22
	destination-address . . . . .	23
	destination-address-range . . . . .	23
	destination-prefix-list . . . . .	24

	from .....	25
	match-direction .....	25
	rule .....	26
	rule-set .....	27
	services .....	27
	source-address .....	28
	source-address-range .....	28
	source-prefix-list .....	29
	syslog .....	29
	term .....	30
	then .....	31
<b>Part 3</b>	<b>Administration</b>	
<b>Chapter 5</b>	<b>Stateful Firewall Operational Mode Commands .....</b>	<b>35</b>
	clear services stateful-firewall flows .....	36
	clear services stateful-firewall statistics .....	38
	show services stateful-firewall flows .....	39
	show services stateful-firewall statistics .....	44
<b>Part 4</b>	<b>Index</b>	
	Index .....	51

# List of Tables

	<b>About the Documentation . . . . .</b>	<b>vii</b>
	Table 1: Notice Icons . . . . .	ix
	Table 2: Text and Syntax Conventions . . . . .	ix
<b>Part 3</b>	<b>Administration</b>	
<b>Chapter 5</b>	<b>Stateful Firewall Operational Mode Commands . . . . .</b>	<b>35</b>
	Table 3: clear services stateful-firewall flows Output Fields . . . . .	37
	Table 4: show services stateful-firewall flows Output Fields . . . . .	41
	Table 5: show services stateful-firewall statistics Output Fields . . . . .	44



# About the Documentation

- Documentation and Release Notes on page vii
- Supported Platforms on page vii
- Using the Examples in This Manual on page vii
- Documentation Conventions on page ix
- Documentation Feedback on page xi
- Requesting Technical Support on page xi

## Documentation and Release Notes

---

To obtain the most current version of all Juniper Networks® technical documentation, see the product documentation page on the Juniper Networks website at <http://www.juniper.net/techpubs/>.

If the information in the latest release notes differs from the information in the documentation, follow the product Release Notes.

Juniper Networks Books publishes books by Juniper Networks engineers and subject matter experts. These books go beyond the technical documentation to explore the nuances of network architecture, deployment, and administration. The current list can be viewed at <http://www.juniper.net/books>.

## Supported Platforms

---

For the features described in this document, the following platforms are supported:

- M Series
- T Series
- MX Series
- J Series

## Using the Examples in This Manual

---

If you want to use the examples in this manual, you can use the **load merge** or the **load merge relative** command. These commands cause the software to merge the incoming configuration into the current candidate configuration. The example does not become active until you commit the candidate configuration.

If the example configuration contains the top level of the hierarchy (or multiple hierarchies), the example is a *full example*. In this case, use the **load merge** command.

If the example configuration does not start at the top level of the hierarchy, the example is a *snippet*. In this case, use the **load merge relative** command. These procedures are described in the following sections.

## Merging a Full Example

To merge a full example, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration example into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following configuration to a file and name the file **ex-script.conf**. Copy the **ex-script.conf** file to the **/var/tmp** directory on your routing platform.

```
system {
  scripts {
    commit {
      file ex-script.xml;
    }
  }
}
interfaces {
  fxp0 {
    disable;
    unit 0 {
      family inet {
        address 10.0.0.1/24;
      }
    }
  }
}
```

2. Merge the contents of the file into your routing platform configuration by issuing the **load merge** configuration mode command:

```
[edit]
user@host# load merge /var/tmp/ex-script.conf
load complete
```

## Merging a Snippet

To merge a snippet, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration snippet into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following snippet to a file and name the file **ex-script-snippet.conf**. Copy the **ex-script-snippet.conf** file to the **/var/tmp** directory on your routing platform.

```
commit {
  file ex-script-snippet.xml; }
```

2. Move to the hierarchy level that is relevant for this snippet by issuing the following configuration mode command:

```
[edit]
user@host# edit system scripts
[edit system scripts]
```

3. Merge the contents of the file into your routing platform configuration by issuing the **load merge relative** configuration mode command:

```
[edit system scripts]
user@host# load merge relative /var/tmp/ex-script-snippet.conf
load complete
```

For more information about the **load** command, see the [Junos OS CLI User Guide](#).

## Documentation Conventions

Table 1 on page ix defines notice icons used in this guide.

Table 1: Notice Icons




Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.

Table 2 on page ix defines the text and syntax conventions used in this guide.

Table 2: Text and Syntax Conventions

Convention	Description	Examples
<b>Bold text like this</b>	Represents text that you type.	To enter configuration mode, type the <b>configure</b> command:  user@host> <b>configure</b>
Fixed-width text like this	Represents output that appears on the terminal screen.	user@host> <b>show chassis alarms</b> No alarms currently active

Table 2: Text and Syntax Conventions (*continued*)

Convention	Description	Examples
<i>Italic text like this</i>	<ul style="list-style-type: none"> <li>Introduces or emphasizes important new terms.</li> <li>Identifies book names.</li> <li>Identifies RFC and Internet draft titles.</li> </ul>	<ul style="list-style-type: none"> <li>A policy <i>term</i> is a named structure that defines match conditions and actions.</li> <li><i>Junos OS System Basics Configuration Guide</i></li> <li>RFC 1997, <i>BGP Communities Attribute</i></li> </ul>
<i>Italic text like this</i>	Represents variables (options for which you substitute a value) in commands or configuration statements.	Configure the machine's domain name:  [edit] root@# <b>set system domain-name</b> <i>domain-name</i>
<b>Text like this</b>	Represents names of configuration statements, commands, files, and directories; configuration hierarchy levels; or labels on routing platform components.	<ul style="list-style-type: none"> <li>To configure a stub area, include the <b>stub</b> statement at the [edit protocols ospf area area-id] hierarchy level.</li> <li>The console port is labeled <b>CONSOLE</b>.</li> </ul>
< > (angle brackets)	Enclose optional keywords or variables.	<b>stub</b> <default-metric <i>metric</i> >;
(pipe symbol)	Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity.	<b>broadcast   multicast</b>  ( <i>string1</i>   <i>string2</i>   <i>string3</i> )
# (pound sign)	Indicates a comment specified on the same line as the configuration statement to which it applies.	<b>rsvp { # Required for dynamic MPLS only</b>
[ ] (square brackets)	Enclose a variable for which you can substitute one or more values.	<b>community name members [</b> <i>community-ids</i> <b>]</b>
Indentation and braces ( { } )	Identify a level in the configuration hierarchy.	[edit] routing-options { static { route default { nexthop <i>address</i> ; retain; } } }
;(semicolon)	Identifies a leaf statement at a configuration hierarchy level.	
<b>J-Web GUI Conventions</b>		
<b>Bold text like this</b>	Represents J-Web graphical user interface (GUI) items you click or select.	<ul style="list-style-type: none"> <li>In the Logical Interfaces box, select <b>All Interfaces</b>.</li> <li>To cancel the configuration, click <b>Cancel</b>.</li> </ul>
> (bold right angle bracket)	Separates levels in a hierarchy of J-Web selections.	In the configuration editor hierarchy, select <b>Protocols&gt;Ospf</b> .

## Documentation Feedback

---

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. You can send your comments to [techpubs-comments@juniper.net](mailto:techpubs-comments@juniper.net), or fill out the documentation feedback form at <https://www.juniper.net/cgi-bin/docbugreport/>. If you are using e-mail, be sure to include the following information with your comments:

- Document or topic name
- URL or page number
- Software release version (if applicable)

## Requesting Technical Support

---

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or JNASC support contract, or are covered under warranty, and need post-sales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the *JTAC User Guide* located at <http://www.juniper.net/us/en/local/pdf/resource-guides/7100059-en.pdf>.
- Product warranties—For product warranty information, visit <http://www.juniper.net/support/warranty/>.
- JTAC hours of operation—The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

## Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <http://www.juniper.net/customers/support/>
- Search for known bugs: <http://www2.juniper.net/kb/>
- Find product documentation: <http://www.juniper.net/techpubs/>
- Find solutions and answer questions using our Knowledge Base: <http://kb.juniper.net/>
- Download the latest versions of software and review release notes: <http://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications: <https://www.juniper.net/alerts/>

- Join and participate in the Juniper Networks Community Forum:  
<http://www.juniper.net/company/communities/>
- Open a case online in the CSC Case Management tool: <http://www.juniper.net/cm/>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool: <https://tools.juniper.net/SerialNumberEntitlementSearch/>

## Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Management tool in the CSC at <http://www.juniper.net/cm/> .
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, see <http://www.juniper.net/support/requesting-support.html> .

## PART 1

# Overview

- [Stateful Firewall on page 3](#)



## CHAPTER 1

# Stateful Firewall

- [Stateful Firewall Overview for JSF on page 3](#)

## Stateful Firewall Overview for JSF

---

Routers use firewalls to track and control the flow of traffic. Adaptive Services and MultiServices PICs employ a type of firewall called a *stateful firewall*. Contrasted with a *stateless* firewall that inspects packets in isolation, a stateful firewall provides an extra layer of security by using state information derived from past communications and other applications to make dynamic control decisions for new communication attempts.

Stateful Firewall (SFW) is supported on the Junos Services Framework (JSF). JSF is a unified framework for the integration of services on Junos-based platforms.

Stateful firewalls group relevant *flows* into *conversations*. A flow is identified by the following five properties:

- Source address
- Source port
- Destination address
- Destination port
- Protocol



**NOTE:** The protocols that are not supported on top of TCP/UDP can have the source port and destination port mapped to other fields.

---

A typical Transmission Control Protocol (TCP) or User Datagram Protocol (UDP) conversation consists of two flows: the initiation flow and the responder flow. However, some conversations, such as an FTP conversation, might consist of two control flows and many data flows.

Firewall rules govern whether the conversation is allowed to be established. If a conversation is allowed, all flows within the conversation are permitted, including flows that are created during the life cycle of the conversation.

You configure stateful firewalls using a powerful rule-driven conversation handling path. A *rule* consists of direction, source address, source port, destination address, destination port, IP protocol value, and application protocol or service. In addition to the specific values you configure, you can assign the value **any** to rule objects, addresses, or ports, which allows them to match any input value. Finally, you can optionally negate the rule objects, which negates the result of the type-specific match.

Firewall rules are directional. For each new conversation, the router software checks the initiation flow matching the direction specified by the rule.

Firewall rules are ordered. The software checks the rules in the order in which you include them in the configuration. The first time the firewall discovers a match, the router implements the action specified by that rule. Rules still unchecked are ignored.

For more information, see [“Configuring Stateful Firewall Rules for JSF” on page 7](#).

## Stateful Firewall Support for Application Protocols

By inspecting the application protocol data, the AS or MultiServices PIC firewall can intelligently enforce security policies and allow only the minimal required packet traffic to flow through the firewall.

The firewall rules are configured in relation to an interface. By default, the stateful firewall allows all sessions initiated from the hosts behind the interface to pass through the router.

## PART 2

# Configuration

- [Configuration Tasks on page 7](#)
- [Example on page 17](#)
- [Configuration Statements on page 21](#)



## CHAPTER 2

# Configuration Tasks

- [Configuring Stateful Firewall Rules for JSF on page 7](#)
- [Configuring Stateful Firewall Rule Sets for JSF on page 10](#)
- [Configuring Juniper Service Framework – Stateful Firewall, Rules, and Services Set on page 10](#)

## Configuring Stateful Firewall Rules for JSF

---

To configure a stateful firewall rule, include the **rule** *rule-name* statement at the **[edit services stateful-firewall]** hierarchy level:

```
[edit services stateful-firewall]
rule rule-name {
  match-direction (input | output | input-output);
  term term-name {
    from {
      application-sets set-name;
      applications [ application-names ];
      destination-address address <except>;
      destination-address-range low minimum-value high maximum-value <except>;
      destination-prefix-list list-name <except>;
      source-address address <except>;
      source-address-range low minimum-value high maximum-value <except>;
      source-prefix-list list-name <except>;
    }
    then {
      (accept | discard | reject);
      allow-ip-options [ values ];
      syslog;
    }
  }
}
```

Each stateful firewall rule consists of a set of terms, similar to a filter configured at the **[edit firewall]** hierarchy level. A term consists of the following:

- **from** statement—Specifies the match conditions and applications that are included and excluded. The **from** statement is optional in stateful firewall rules.
- **then** statement—Specifies the actions and action modifiers to be performed by the router software. The **then** statement is mandatory in stateful firewall rules.

The following sections explain how to configure the components of stateful firewall rules:

- [Configuring Match Direction for Stateful Firewall Rules on page 8](#)
- [Configuring Match Conditions in Stateful Firewall Rules on page 8](#)
- [Configuring Actions in Stateful Firewall Rules on page 9](#)

## Configuring Match Direction for Stateful Firewall Rules

Each rule must include a **match-direction** statement that specifies the direction in which the rule match is applied. To configure where the match is applied, include the **match-direction** statement at the **[edit services stateful-firewall rule *rule-name*]** hierarchy level:

```
[edit services stateful-firewall rule rule-name]  
match-direction (input | output | input-output);
```

If you configure **match-direction input-output**, sessions initiated from both directions might match this rule.

The match direction is used with respect to the traffic flow through the AS or Multiservices PIC. When a packet is sent to the PIC, direction information is carried along with it.

With an interface service set, packet direction is determined by whether a packet is entering or leaving the interface on which the service set is applied.

With a next-hop service set, packet direction is determined by the interface used to route the packet to the AS or Multiservices PIC. If the inside interface is used to route the packet, the packet direction is input. If the outside interface is used to direct the packet to the PIC, the packet direction is output.

On the PIC, a flow lookup is performed. If no flow is found, rule processing is performed. Rules in this service set are considered in sequence until a match is found. During rule processing, the packet direction is compared against rule directions. Only rules with direction information that matches the packet direction are considered. Most packets result in the creation of bidirectional flows.

## Configuring Match Conditions in Stateful Firewall Rules

To configure stateful firewall match conditions, include the **from** statement at the **[edit services stateful-firewall rule *rule-name* term *term-name*]** hierarchy level:

```
[edit services stateful-firewall rule rule-name term term-name]  
from {  
  application-sets set-name;  
  applications [ application-names ];  
  destination-address address <except>;  
  destination-address-range low minimum-value high maximum-value <except>;  
  destination-prefix-list list-name <except>;  
  source-address address <except>;  
  source-address-range low minimum-value high maximum-value <except>;  
  source-prefix-list list-name <except>;  
}
```

The source address and destination address can be either IPv4 or IPv6. You can use either the source address or the destination address as a match condition, in the same way that you would configure a firewall filter; for more information, see the [Junos OS Policy Framework Configuration Guide](#). You can use the wildcard value **any-unicast**, which denotes matching all unicast addresses.

Alternatively, you can specify a list of source or destination prefixes by configuring the **prefix-list** statement at the **[edit policy-options]** hierarchy level and then including either the **destination-prefix-list** or the **source-prefix-list** statement in the stateful firewall rule. For an example, see “[Examples: Configuring Stateful Firewall Rules for JSF](#)” on page 17.

If you omit the **from** term, the stateful firewall accepts all traffic and the default protocol handlers take effect:

- User Datagram Protocol (UDP), Transmission Control Protocol (TCP), and Internet Control Message Protocol (ICMP) create a bidirectional flow with a predicted reverse flow.

You can also include application protocol definitions you have configured at the **[edit applications]** hierarchy level.

- To apply one or more specific application protocol definitions, include the **applications** statement at the **[edit services stateful-firewall rule rule-name term term-name from]** hierarchy level.
- To apply one or more sets of application protocol definitions you have defined, include the **application-sets** statement at the **[edit services stateful-firewall rule rule-name term term-name from]** hierarchy level.



**NOTE:** If you include one of the statements that specifies application protocols, the router derives port and protocol information from the corresponding configuration at the **[edit applications]** hierarchy level; you cannot specify these properties as match conditions.

## Configuring Actions in Stateful Firewall Rules

To configure stateful firewall actions, include the **then** statement at the **[edit services stateful-firewall rule rule-name term term-name]** hierarchy level:

```
[edit services stateful-firewall rule rule-name term term-name]
then {
  (accept | discard | reject);
  syslog;
}
```

You must include one of the following three possible actions:

- **accept**—The packet is accepted and sent on to its destination.
- **discard**—The packet is not accepted and is not processed further.

- **reject**—The packet is not accepted and a rejection message is returned; UDP sends an ICMP unreachable code and TCP sends RST. Rejected packets can be logged or sampled.

You can optionally configure the firewall to record information in the system logging facility by including the **syslog** statement at the **[edit services stateful-firewall rule rule-name term term-name then]** hierarchy level. This statement overrides any **syslog** setting included in the service set or interface default configuration.

## Configuring Stateful Firewall Rule Sets for JSF

---

The **rule-set** statement defines a collection of stateful firewall rules that determine what actions the router software performs on packets in the data stream. You define each rule by specifying a rule name and configuring terms. Then, you specify the order of the rules by including the **rule-set** statement at the **[edit services stateful-firewall]** hierarchy level with a **rule** statement for each rule:

```
[edit services stateful-firewall]
rule-set rule-set-name {
  rule rule-name;
}
```

The router software processes the rules in the order in which you specify them in the configuration. If a term in a rule matches the packet, the router performs the corresponding action and the rule processing stops. If no term in a rule matches the packet, processing continues to the next rule in the rule set. If none of the rules matches the packet, the packet is dropped by default.

## Configuring Juniper Service Framework – Stateful Firewall, Rules, and Services Set

---

Routers use firewalls to track and control the flow of traffic. Adaptive Services and Multiservices PICs employ a type of firewall called a stateful firewall. To use JSF to run Stateful Firewall, you must configure the `jservices-sfw` package at the hierarchy level. In addition, you must configure SFW rules and a services set with a Multiservice interface. This section includes the following tasks:

1. [Configuring the JSF Stateful Firewall Package on page 10](#)
2. [Configuring the Stateful Firewall Rule on page 12](#)
3. [Configuring the Services Set for Stateful Firewall on page 13](#)

### Configuring the JSF Stateful Firewall Package

To configure the JSF services:

1. In configuration mode, go to the following hierarchy level:  

```
user@host# edit chassis
```
2. In the hierarchy level, configure the FPC and PIC.  

```
[edit chassis]
user@host# edit fpc slot pic slot
```

In this example, the FPC is in slot 1 and the PIC is in slot 0:

```
[edit chassis]
user@host# edit fpc 1 pic 0
```

3. Configure the number of cores dedicated to run control functionality.

```
[edit chassis fpc slot pic slot]
user@host# set adaptive-services service-package extension-provider control-cores
control-cores
```

In this example, the number of control cores is 1.

```
[edit chassis fpc 1 pic 0]
user@host# set adaptive-services service-package extension-provider control-cores
1
```

4. Configure the number of processing cores dedicated to data.

```
[edit chassis fpc slot pic slot]
user@host# set adaptive-services service-package extension-provider data-cores
data-cores
```

In this example, the number of data cores is 7.

```
[edit chassis fpc 1 pic 0]
user@host# set adaptive-services service-package extension-provider data-cores 7
```

5. Configure the size of the object cache in MB. Only values in increments of 128 MB are allowed and the maximum value of object cache can be 1280 MB. To configure the size of the cache:

```
[edit chassis fpc slot pic slot]
user@host# set adaptive-services service-package extension-provider
object-cache-size object-cache-size
```

In this example, the size of the object cache is 1280 MB.

```
[edit chassis fpc 1 pic 0]
user@host# set adaptive-services service-package extension-provider
object-cache-size 1280
```

6. Configure the size of the policy database in MB.

```
[edit chassis fpc slot pic slot]
user@host# set adaptive-services service-package extension-provider policy-db-size
policy-db-size
```

In this example, the size of the policy database is 64 MB.

```
[edit chassis fpc 1 pic 0]
user@host# set adaptive-services service-package extension-provider policy-db-size
64
```

7. Configure the package.

```
[edit chassis fpc slot pic slot]
user@host# set adaptive-services service-package extension-provider package
package
```

In this example, the package is **jservices-nat**.

```
[edit chassis fpc 1 pic 0]
user@host# set adaptive-services service-package extension-provider package
jservices-nat
```

8. Configure the extension provider system log, to enable PIC system logging to record or view system log messages:

```
[edit chassis fpc slot pic slot]
user@host# set adaptive-services service-package extension-provider syslog syslog
```

In this example **syslog** is set to **daemon any** and **external any**:

```
[edit chassis fpc 1 pic 0]
user@host# set adaptive-services service-package extension-provider syslog daemon
any
[edit chassis fpc 1 pic 0]
user@host# set adaptive-services service-package extension-provider syslog external
any
```

9. Verify the configuration.

```
[edit chassis]
user@host# show chassis
fpc 1 {
  pic 0 {
    adaptive-services {
      service-package {
        extension-provider {
          control-cores 1;
          data-cores 7;
          object-cache-size 1280;
          policy-db-size 64;
          package jservices-nat;
          syslog {
            daemon any;
            external any;
          }
        }
      }
    }
  }
}
```

## Configuring the Stateful Firewall Rule

To configure the stateful firewall rule:

1. In configuration mode, go to the following hierarchy level:

```
user@host# edit services
```

2. Configure the Stateful Firewall rule.

```
[edit services]
user@host# set stateful-firewall rule rule
```

In this example, the SFW rule is **rule1 match-direction input-output**.

```
[edit services]
```

```
user@host# set stateful-firewall rule rule1 match-direction input-output
```

3. Configure the rule input conditions for a rule to define the stateful firewall term.

```
[edit services]
user@host# set stateful-firewall rule rule
```

In this example, the rule input conditions are **rule1 term term1 from applications junos-tftp** and **rule1 term term1 from applications junos-rsh**

```
[edit services]
user@host# set stateful-firewall rule rule1 term term1 from applications junos-tftp
user@host# set stateful-firewall rule rule1 term term1 from applications junos-rsh
```

4. Configure the rule for the stateful firewall term actions.

```
[edit services]
user@host# set stateful-firewall rule rule
```

In this example, the rule is **rule1 term term1 then accept**.

```
[edit services]
user@host# set stateful-firewall rule rule1 term term1 then accept
```

5. Verify the configuration.

```
[edit services]
stateful-firewall {
  rule rule1 {
    match-direction input-output;
    term term1 {
      from {
        applications [ junos-tftp junos-rsh ];
      }
      then {
        accept;
      }
    }
  }
}
```

## Configuring the Services Set for Stateful Firewall

To configure the services set for stateful firewall:

1. In configuration mode, go to the following hierarchy level:

```
user@host# edit services
```

2. Configure the services set.

```
[edit services]
user@host# edit service-set service-set
```

In this example, the services set with a rule is **sfw-ss**.

```
[edit services]
user@host# edit service-set sfw-ss
```

3. Configure the services set message rate limit.

```
[edit services service-set sfw-ss]
```

```
user@host# edit syslog syslog
```

In this example, the service set message rate limit is set to **syslog**, which is the maximum number of system log messages per second allowed from this interface.

```
[edit services service-set sfw-ss]
user@host# edit syslog
```

4. Configure the host attributes.

```
[edit services service-set sfw-ss syslog]
user@host# edit host host
```

In this example, the host is **host-local**.

```
[edit services service-set sfw-ss syslog]
user@host# edit host host-local
```

5. Configure the services with services attributes.

```
[edit services service-set sfw-ss syslog host host-local]
user@host# set services services
```

In this example, the services attribute is **any**.

```
[edit services service-set sfw-ss syslog host host-local]
user@host# set services any
```

6. Configure the services set with SFW rules.

```
[edit services service-set sfw-ss]
user@host# edit stateful-firewall-rules stateful-firewall-rules
```

In this example, the SFW rule is **rule1**.

```
[edit services service-set sfw-ss]
user@host# edit stateful-firewall-rules rule1
```

7. Configure the interface.

```
[edit services service-set sfw-ss]
user@host# edit interface interface
```

In this example, the interface is **interface-service**.

```
[edit services service-set sfw-ss]
user@host# edit interface interface-service
```

8. Configure the service interface.

```
[edit services service-set sfw-ss interface-service]
user@host# set service-interface service-interface
```

In this example, the interface is **ms-1/0/0**.

```
[edit services service-set sfw-ss interface-service]
user@host# set service-interface ms-1/0/0
```

9. Verify the configuration.

```
[edit services]
user@host# show services
service-set sfw-ss {
    syslog {
```

```
        host local {  
            services any;  
        }  
    }  
    stateful-firewall-rules rule1;  
    interface-service {  
        service-interface ms-1/0/0;  
    }  
}
```



## CHAPTER 3

# Example

- [Examples: Configuring Stateful Firewall Rules for JSF on page 17](#)

### Examples: Configuring Stateful Firewall Rules for JSF

---

The following example shows a stateful firewall configuration containing two rules, one for input matching on a specified application set and the other for output matching on a specified source address:

```
[edit services]
stateful-firewall {
  rule Rule1 {
    match-direction input;
    term 1 {
      from {
        application-sets Applications;
      }
      then {
        accept;
      }
    }
    term accept {
      then {
        accept;
      }
    }
  }
}
rule Rule2 {
  match-direction output;
  term Local {
    from {
      source-address {
        10.1.3.2/32;
      }
    }
    then {
      accept;
    }
  }
}
```

The following example has a single rule with two terms. The first term rejects all traffic in **my-application-group** that originates from the specified source address, and provides a detailed system log record of the rejected packets. The second term accepts Hypertext Transfer Protocol (HTTP) traffic from anyone to the specified destination address.

```
[edit services stateful-firewall]
rule my-firewall-rule {
  match-direction input-output;
  term term1 {
    from {
      source-address 10.1.3.2/32;
      application-sets my-application-group;
    }
    then {
      reject;
      syslog;
    }
  }
  term term2 {
    from {
      destination-address 10.2.3.2/32;
      applications http;
    }
    then {
      accept;
    }
  }
}
```

The following example shows use of source and destination prefix lists. This requires two separate configuration items.

You configure the prefix list at the **[edit policy-options]** hierarchy level:

```
[edit]
policy-options {
  prefix-list p1 {
    1.1.1.1/32;
    2.2.2.0/24;
  }
  prefix-list p2 {
    3.3.3.3/32;
    4.4.4.0/24;
  }
}
```

You reference the configured prefix list in the stateful firewall rule:

```
[edit]
services {
  stateful-firewall {
    rule r1 {
      match-direction input;
      term t1 {
        from {
          source-prefix-list {
```

```

        p1;
    }
    destination-prefix-list {
        p2;
    }
}
then {
    accept;
}
}
}
}
}
}

```

This is equivalent to the following configuration:

```

[edit]
services {
  stateful-firewall {
    rule r1 {
      match-direction input;
      term t1 {
        from {
          source-address {
            1.1.1.1/32;
            2.2.2.0/24;
          }
          destination-address {
            3.3.3.3/32;
            4.4.4.0/24;
          }
        }
        then {
          accept;
        }
      }
    }
  }
}

```

You can use the **except** qualifier with the prefix lists, as in the following example. In this case, the **except** qualifier applies to all prefixes included in prefix list **p2**.

```

[edit]
services {
  stateful-firewall {
    rule r1 {
      match-direction input;
      term t1 {
        from {
          source-prefix-list {
            p1;
          }
          destination-prefix-list {
            p2 except;
          }
        }
      }
    }
  }
}

```

```
    }  
    then {  
        accept;  
    }  
}  
}  
}
```

For additional examples that combine stateful firewall configuration with other services and with virtual private network (VPN) routing and forwarding (VRF) tables, see the configuration examples.

## CHAPTER 4

# Configuration Statements

### allow-ip-options

---

**Syntax**    `allow-ip-options [ values ];`

**Hierarchy Level**    `[edit services stateful-firewall rule rule-name term term-name then]`

**Release Information**    Statement introduced in Junos OS Release 10.4.

**Description**    Configure how the stateful firewall handles IP header information. This statement is optional.

**Options**    *value*—Can be a set or range of numeric values, or one or more of the following predefined option types. You can enter either the option name or its numeric equivalent.

Option Name	Numeric Value
any	0
ip-security	130
ip-stream	8
loose-source-route	3
route-record	7
router-alert	148
strict-source-route	9
timestamp	4

**Usage Guidelines**    See “[Configuring Stateful Firewall Rules for JSF](#)” on page 7.

**Required Privilege Level**    interface—To view this statement in the configuration.  
   interface-control—To add this statement to the configuration.

## application-sets

---

<b>Syntax</b>	<code>applications-sets <i>set-name</i>;</code>
<b>Hierarchy Level</b>	[edit <a href="#">services</a> stateful-firewall <a href="#">rule</a> <i>rule-name</i> <a href="#">term</a> <i>term-name</i> <a href="#">from</a> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.4.
<b>Description</b>	Define one or more target application sets.
<b>Options</b>	<i>set-name</i> —Name of the target application set.
<b>Usage Guidelines</b>	See “ <a href="#">Configuring Stateful Firewall Rules for JSF</a> ” on page 7.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

## applications

---

<b>Syntax</b>	<code>applications [ <i>application-names</i> ];</code>
<b>Hierarchy Level</b>	[edit <a href="#">services</a> stateful-firewall <a href="#">rule</a> <i>rule-name</i> <a href="#">term</a> <i>term-name</i> <a href="#">from</a> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.4.
<b>Description</b>	Define one or more applications to which the stateful firewall services apply.
<b>Options</b>	<i>application-name</i> —Name of the target application.
<b>Usage Guidelines</b>	See “ <a href="#">Configuring Stateful Firewall Rules for JSF</a> ” on page 7.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

## destination-address

---

<b>Syntax</b>	<code>destination-address (address   any-unicast) &lt;except&gt;;</code>
<b>Hierarchy Level</b>	[edit <a href="#">services</a> stateful-firewall <a href="#">rule</a> rule-name <a href="#">term</a> term-name <a href="#">from</a> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.4.
<b>Description</b>	Specify the destination address for rule matching.
<b>Options</b>	<p><b>address</b>—Destination IPv4 or IPv6 address or prefix value.</p> <p><b>any-unicast</b>—Match all unicast packets.</p> <p><b>except</b>—(Optional) Exclude the specified address, prefix, or unicast packets from rule matching.</p>
<b>Usage Guidelines</b>	See “ <a href="#">Configuring Stateful Firewall Rules for JSF</a> ” on page 7.
<b>Required Privilege Level</b>	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

## destination-address-range

---

<b>Syntax</b>	<code>destination-address-range low minimum-value high maximum-value &lt;except&gt;;</code>
<b>Hierarchy Level</b>	[edit <a href="#">services</a> stateful-firewall <a href="#">rule</a> rule-name <a href="#">term</a> term-name <a href="#">from</a> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.4.
<b>Description</b>	Specify the destination address range for rule matching.
<b>Options</b>	<p><b>minimum-value</b>—Lower boundary for the IPv4 or IPv6 address range.</p> <p><b>maximum-value</b>—Upper boundary for the IPv4 or IPv6 address range.</p> <p><b>except</b>—(Optional) Exclude the specified address range from rule matching.</p>
<b>Usage Guidelines</b>	See “ <a href="#">Configuring Stateful Firewall Rules for JSF</a> ” on page 7.
<b>Required Privilege Level</b>	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

## destination-prefix-list

---

<b>Syntax</b>	<code>destination-prefix-list <i>list-name</i> &lt;except&gt;;</code>
<b>Hierarchy Level</b>	[edit <a href="#">services</a> stateful-firewall <a href="#">rule</a> <i>rule-name</i> <a href="#">term</a> <i>term-name</i> <a href="#">from</a> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.4.
<b>Description</b>	Specify the destination prefix list for rule matching. You configure the prefix list by including the <b>prefix-list</b> statement at the [edit <b>policy-options</b> ] hierarchy level.
<b>Options</b>	<b><i>list-name</i></b> —Destination prefix list. <b>except</b> —(Optional) Exclude the specified prefix list from rule matching.
<b>Usage Guidelines</b>	See “ <a href="#">Configuring Stateful Firewall Rules for JSF</a> ” on page 7.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Documentation</b>	<ul style="list-style-type: none"><li>• <a href="#">Junos OS Policy Framework Configuration Guide</a></li></ul>

## from

---

<b>Syntax</b>	<pre> from {   application-sets set-name;   applications [ application-names ];   destination-address address &lt;except&gt;;   destination-address-range low minimum-value high maximum-value &lt;except&gt;;   destination-prefix-list list-name &lt;except&gt;;   source-address address &lt;except&gt;;   source-address-range low minimum-value high maximum-value &lt;except&gt;;   source-prefix-list list-name &lt;except&gt;; } </pre>
<b>Hierarchy Level</b>	[edit <a href="#">services</a> stateful-firewall <a href="#">rule</a> rule-name <a href="#">term</a> term-name]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.4.
<b>Description</b>	Specify input conditions for a stateful firewall term.
<b>Options</b>	<p>For information on match conditions, see the description of firewall filter match conditions in the <i>Junos OS Policy Framework Configuration Guide</i>.</p> <p>The remaining statements are explained separately.</p>
<b>Usage Guidelines</b>	See “Configuring Stateful Firewall Rules for JSF” on page 7.
<b>Required Privilege Level</b>	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

## match-direction

---

<b>Syntax</b>	match-direction (input   output   input-output);
<b>Hierarchy Level</b>	[edit <a href="#">services</a> stateful-firewall <a href="#">rule</a> rule-name]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.4.
<b>Description</b>	Specify the direction in which the rule match is applied.
<b>Options</b>	<p><b>input</b>—Apply the rule match on the input side of the interface.</p> <p><b>output</b>—Apply the rule match on the output side of the interface.</p> <p><b>input-output</b>—Apply the rule match bidirectionally.</p>
<b>Usage Guidelines</b>	See “Configuring Stateful Firewall Rules for JSF” on page 7.
<b>Required Privilege Level</b>	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

## rule

---

Syntax	<pre>rule rule-name {   match-direction (input   output   input-output);   term term-name {     from {       application-sets set-name;       applications [ application-names ];       destination-address address &lt;except&gt;;       destination-address-range low minimum-value high maximum-value &lt;except&gt;;       destination-prefix-list list-name &lt;except&gt;;       source-address address &lt;except&gt;;       source-address-range low minimum-value high maximum-value &lt;except&gt;;       source-prefix-list list-name &lt;except&gt;;     }     then {       (accept   discard   reject);       syslog;     }   } }</pre>
Hierarchy Level	[edit <a href="#">services</a> stateful-firewall], [edit <a href="#">services</a> stateful-firewall <a href="#">rule-set</a> rule-set-name]
Release Information	Statement introduced in Junos OS Release 10.4.
Description	Specify the rule the router uses when applying this service.
Options	<b>rule-name</b> —Identifier for the collection of terms that constitute this rule.  The remaining statements are explained separately.
Usage Guidelines	See “ <a href="#">Configuring Stateful Firewall Rules for JSF</a> ” on <a href="#">page 7</a> .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

## rule-set

---

<b>Syntax</b>	<code>rule-set <i>rule-set-name</i> {     [ <i>rule</i> <i>rule-names</i> ]; }</code>
<b>Hierarchy Level</b>	[edit <i>services</i> stateful-firewall]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.4.
<b>Description</b>	Specify the rule set the router uses when applying this service.
<b>Options</b>	<i>rule-set-name</i> —Identifier for the collection of rules that constitute this rule set.
<b>Usage Guidelines</b>	See “ <a href="#">Configuring Stateful Firewall Rule Sets for JSF</a> ” on page 10.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

## services

---

<b>Syntax</b>	<code>services stateful-firewall { ... }</code>
<b>Hierarchy Level</b>	[edit]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.4.
<b>Description</b>	Define the service rules to be applied to traffic.
<b>Options</b>	<i>stateful-firewall</i> —Identifies the stateful firewall set of rules statements.
<b>Usage Guidelines</b>	See “ <a href="#">Stateful Firewall Overview for JSF</a> ” on page 3.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

## source-address

---

<b>Syntax</b>	source-address ( <i>address</i>   any-unicast) <except>;
<b>Hierarchy Level</b>	[edit <a href="#">services</a> stateful-firewall <a href="#">rule</a> <i>rule-name</i> <a href="#">term</a> <i>term-name</i> <a href="#">from</a> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.4.
<b>Description</b>	Source address for rule matching.
<b>Options</b>	<i>address</i> —Source IPv4 or IPv6 address or prefix value. <i>any-unicast</i> —Any unicast packet. <i>except</i> —(Optional) Exclude the specified address, prefix, or unicast packets from rule matching.
<b>Usage Guidelines</b>	See “ <a href="#">Configuring Stateful Firewall Rules for JSF</a> ” on <a href="#">page 7</a> .
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

## source-address-range

---

<b>Syntax</b>	source-address-range low <i>minimum-value</i> high <i>maximum-value</i> <except>;
<b>Hierarchy Level</b>	[edit <a href="#">services</a> stateful-firewall <a href="#">rule</a> <i>rule-name</i> <a href="#">term</a> <i>term-name</i> <a href="#">from</a> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.4.
<b>Description</b>	Source address range for rule matching.
<b>Options</b>	<i>minimum-value</i> —Lower boundary for the IPv4 or IPv6 address range. <i>maximum-value</i> —Upper boundary for the IPv4 or IPv6 address range. <i>except</i> —(Optional) Exclude the specified address, prefix, or unicast packets from rule matching.
<b>Usage Guidelines</b>	See “ <a href="#">Configuring Stateful Firewall Rules for JSF</a> ” on <a href="#">page 7</a> .
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

## source-prefix-list

<b>Syntax</b>	<code>source-prefix-list <i>list-name</i> &lt;except&gt;;</code>
<b>Hierarchy Level</b>	[edit <a href="#">services</a> stateful-firewall <a href="#">rule</a> <i>rule-name</i> <a href="#">term</a> <i>term-name</i> <a href="#">from</a> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.4.
<b>Description</b>	Specify the source prefix list for rule matching. You configure the prefix list by including the <b>prefix-list</b> statement at the [edit <b>policy-options</b> ] hierarchy level.
<b>Options</b>	<p><b>list-name</b>—Destination prefix list.</p> <p><b>except</b>—(Optional) Exclude the specified prefix list from rule matching.</p>
<b>Usage Guidelines</b>	See “ <a href="#">Configuring Stateful Firewall Rules for JSF</a> ” on page 7.
<b>Required Privilege Level</b>	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Junos OS Policy Framework Configuration Guide</a></li> </ul>

## syslog

<b>Syntax</b>	<code>syslog;</code>
<b>Hierarchy Level</b>	[edit <a href="#">services</a> stateful-firewall <a href="#">rule</a> <i>rule-name</i> <a href="#">term</a> <i>term-name</i> <a href="#">then</a> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.4.
<b>Description</b>	Enable system logging. The system log information from the Adaptive Services or Multiservices PIC is passed to the kernel for logging in the <code>/var/log</code> directory. This setting overrides any <b>syslog</b> statement setting included in the service set or interface default configuration.
<b>Usage Guidelines</b>	See “ <a href="#">Configuring Stateful Firewall Rules for JSF</a> ” on page 7.
<b>Required Privilege Level</b>	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

## term

---

**Syntax**    `term term-name {  
              from {  
                  application-sets set-name;  
                  applications [ application-names ];  
                  destination-address address <except>;  
                  destination-address-range low minimum-value high maximum-value <except>;  
                  destination-prefix-list list-name <except>;  
                  source-address address <except>;  
                  source-address-range low minimum-value high maximum-value <except>;  
                  source-prefix-list list-name <except>;  
              }  
              then {  
                  (accept | discard | reject);  
                  syslog;  
              }  
          }`

**Hierarchy Level**    [edit [services](#) stateful-firewall [rule](#) *rule-name*]

**Release Information**    Statement introduced in Junos OS Release 10.4.

**Description**    Define the stateful firewall term properties.

**Options**    *term-name*—Identifier for the term.

The remaining statements are explained separately.

**Usage Guidelines**    See “[Configuring Stateful Firewall Rules for JSF](#)” on page 7.

**Required Privilege**    interface—To view this statement in the configuration.

**Level**    interface-control—To add this statement to the configuration.

## then

---

<b>Syntax</b>	<pre>then {   (accept   discard   reject);   syslog; }</pre>
<b>Hierarchy Level</b>	[edit <a href="#">services</a> stateful-firewall <a href="#">rule</a> <i>rule-name</i> <a href="#">term</a> <i>term-name</i> ]
<b>Release Information</b>	Statement introduced in Junos OS Release 10.4.
<b>Description</b>	Define the stateful firewall term actions. You can configure the router to accept, discard, or reject the targeted traffic. The other actions are optional.
<b>Options</b>	<p><b>accept</b>—Accept the traffic and send it on to its destination.</p> <p><b>discard</b>—Do not accept traffic or process it further.</p> <p><b>reject</b>—Do not accept the traffic and return a rejection message. Rejected traffic can be logged or sampled.</p> <p>The remaining statement is explained separately.</p>
<b>Usage Guidelines</b>	See “ <a href="#">Configuring Stateful Firewall Rules for JSF</a> ” on <a href="#">page 7</a> .
<b>Required Privilege Level</b>	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li>• <a href="#">Junos OS Policy Framework Configuration Guide</a></li> </ul>



## PART 3

# Administration

- [Stateful Firewall Operational Mode Commands on page 35](#)



## CHAPTER 5

# Stateful Firewall Operational Mode Commands

## clear services stateful-firewall flows

---

<b>Syntax</b>	<pre>clear services stateful-firewall flows &lt;application-protocol <i>protocol</i>&gt; &lt;destination-port <i>destination-port</i>&gt; &lt;destination-prefix <i>destination-prefix</i>&gt; &lt;interface <i>interface-name</i>&gt; &lt;protocol <i>protocol</i>&gt; &lt;service-set <i>service-set</i>&gt; &lt;source-port <i>source-port</i>&gt; &lt;source-prefix <i>source-prefix</i>&gt;</pre>
<b>Release Information</b>	Command introduced in Junos OS Release 10.4.
<b>Description</b>	Clear stateful firewall flows.
<b>Options</b>	<p><b>none</b>—Clear all stateful firewall flows.</p> <p><b>destination-port <i>destination-port</i></b>—(Optional) Clear stateful firewall flows for a particular destination port. The range of values is 0 to 65535.</p> <p><b>destination-prefix <i>destination-prefix</i></b>—(Optional) Clear stateful firewall flows for a particular destination prefix.</p> <p><b>interface <i>interface-name</i></b>—(Optional) Clear stateful firewall flows for a particular interface. On M Series and T Series routers, the <i>interface-name</i> can be <i>ms-fpc/pic/port</i> or <i>rspnumber</i>. On J Series routers, the <i>interface-name</i> is <i>ms-pim/0/port</i>.</p> <p><b>protocol</b>—(Optional) Clear stateful firewall flows for one of the following IP types:</p> <ul style="list-style-type: none"><li>• <b>number</b>—Numeric protocol value from 0 to 255.</li><li>• <b>ah</b>—IPsec Authentication Header protocol</li><li>• <b>egp</b>—An exterior gateway protocol</li><li>• <b>esp</b>—IPsec Encapsulating Security Payload protocol</li><li>• <b>gre</b>—A generic routing encapsulation protocol</li><li>• <b>icmp</b>—Internet Control Message Protocol</li><li>• <b>igmp</b>—Internet Group Management Protocol</li><li>• <b>ipip</b>—IP-over-IP Encapsulation Protocol</li><li>• <b>ospf</b>—Open Shortest Path First protocol</li><li>• <b>pim</b>—Protocol Independent Multicast protocol</li><li>• <b>rsvp</b>—Resource Reservation Protocol</li><li>• <b>sctp</b>—Stream Control Protocol</li><li>• <b>tcp</b>—Transmission Control Protocol</li><li>• <b>udp</b>—User Datagram Protocol</li></ul>

**service-set** *service-set*—(Optional) Clear stateful firewall flows for a particular service set.

**source-port** *source-port*—(Optional) Clear stateful firewall flows for a particular source port. The range of values is from 0 through 65535.

**source-prefix** *source-prefix*—(Optional) Clear stateful firewall flows for a particular source prefix.

**Required Privilege Level** view

**Related Documentation** • [show services stateful-firewall flows on page 39](#)

**List of Sample Output** [clear services stateful-firewall flows on page 37](#)

**Output Fields** [Table 3 on page 37](#) lists the output fields for the **clear services stateful-firewall flows** command. Output fields are listed in the approximate order in which they appear.

**Table 3: clear services stateful-firewall flows Output Fields**

Field Name	Field Description
<b>Interface</b>	Name of an adaptive services interface.
<b>Service set</b>	Name of the service set from which flows are being cleared.
<b>Conv removed</b>	Number of conversations removed.

## Sample Output

```
clear services stateful-firewall flows
user@host> clear services stateful-firewall flows
Interface  Service set  Conv removed
ms-0/3/0   svc_set_trust 0
ms-0/3/0   svc_set_untrust 0
```

## clear services stateful-firewall statistics

---

Syntax	clear services stateful-firewall statistics <interface <i>interface-name</i> > <service-set <i>service-set</i> >
Release Information	Command introduced in Junos OS Release 10.4.
Description	Clear stateful firewall statistics.
Options	<b>none</b> —Clear stateful firewall statistics for all interfaces and all service sets.  <b>interface <i>interface-name</i></b> —(Optional) Clear stateful firewall statistics for the specified interface. On M Series and T Series routers, the <i>interface-name</i> can be <b>ms-fpc/pic/port</b> or <b>rspnumber</b> . On J Series routers, the <i>interface-name</i> is <b>ms-pim/0/port</b> .  <b>service-set <i>service-set</i></b> —(Optional) Clear stateful firewall statistics for the specified service set.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"><li>• <a href="#">show services stateful-firewall statistics on page 44</a></li></ul>
List of Sample Output	<a href="#">clear services stateful-firewall statistics on page 38</a>
Output Fields	When you enter this command, you are provided feedback on the status of your request.

### Sample Output

clear services stateful-firewall statistics	user@host> clear services stateful-firewall statistics
---	--

## show services stateful-firewall flows

**Syntax** show services stateful-firewall flows  
 <brief | extensive | summary | terse>  
 <application-protocol *protocol*>  
 <count>  
 <destination-port *destination-port*>  
 <destination-prefix *destination-prefix*>  
 <interface *interface-name*>  
 <limit *number*>  
 <protocol *protocol*>  
 <service-set *service-set*>  
 <source-port *source-port*>  
 <source-prefix *source-prefix*>

**Release Information** Command introduced in Junos OS Release 10.4.

**Description** Display stateful firewall flow table entries. When the interface is used for software processing, the type of software concentrator (**DS-LITE** or **6rd**) is shown, and frame counts are provided.

**Options** **none**—Display standard information about all stateful firewall flows.

**brief | extensive | summary | terse**—(Optional) Display the specified level of output.

**application-protocol *application-protocol***—(Optional) Display information about one of the following application-level gateway (ALG) protocol types:

- **bootp**—Bootstrap protocol
- **dce-rpc**—Distributed Computing Environment (DCE) remote procedure call (RPC) protocol



**NOTE:** Use this option to select Microsoft Remote Procedure Call (MSRPC).

- **dce-rpc-portmap**—Distributed Computing Environment (DCE) remote procedure call (RPC) portmap protocol
- **dns**—Domain Name Service protocol
- **exec**—Remote execution protocol
- **ftp**—File Transfer Protocol
- **h323**—H.323 protocol
- **icmp**—Internet Control Message Protocol
- **iiop**—Internet Inter-ORB Protocol
- **ip**—Internet protocol
- **netbios**—NetBIOS protocol

- **netshow**—Netshow protocol
- **pptp** —Point-to-Point Tunneling Protocol
- **realaudio**—RealAudio protocol
- **rpc**—Remote Procedure Call protocol



**NOTE:** Use this option to select Sun Microsystems Remote Procedure Call protocol (SunRPC).

- **rpc-portmap**—Remote Procedure Call portmap protocol
- **rtsp**—Real-Time Streaming Protocol
- **sip**—Session Initiation Protocol
- **snmp**—Simple Network Management Protocol
- **talk**—Talk protocol
- **tftp**—Trivial File Transfer Protocol
- **traceroute**—Traceroute
- **winframe**—WinFrame

**count**—(Optional) Display a count of the matching entries.

**destination-port *destination-port***—(Optional) Display information for a particular destination port. The range of values is from 0 to 65535.

**destination-prefix *destination-prefix***—(Optional) Display information for a particular destination prefix.

**interface *interface-name***—(Optional) Display information about a particular interface.  
On M Series and T Series routers, *interface-name* can be *ms-fpc/pic/port* or *rspnumber*.  
On J Series routers, *interface-name* is *ms-pim/0/port*.

**limit *number***—(Optional) Maximum number of entries to display.

**protocol *protocol***—(Optional) Display information about one of the following IP types:

- ***number***—Numeric protocol value from 0 to 255
- **ah**—IPsec Authentication Header protocol
- **egp**—An exterior gateway protocol
- **esp**—IPsec Encapsulating Security Payload protocol
- **gre**—A generic routing encapsulation protocol
- **icmp**—Internet Control Message Protocol
- **igmp**—Internet Group Management Protocol

- **ipip**—IP-within-IP Encapsulation Protocol
- **ospf**—Open Shortest Path First protocol
- **pim**—Protocol Independent Multicast protocol
- **rsvp**—Resource Reservation Protocol
- **sctp**—Stream Control Protocol
- **tcp**—Transmission Control Protocol
- **udp**—User Datagram Protocol

**service-set *service-set***—(Optional) Display information for a particular service set.

**source-port *source-port***—(Optional) Display information for a particular source port. The range of values is from 0 to 65535.

**source-prefix *source-prefix***—(Optional) Display information for a particular source prefix.

**Required Privilege Level** view

**Related Documentation** [• clear services stateful-firewall flows on page 36](#)

**List of Sample Output** [show services stateful-firewall flows on page 42](#)  
[show services stateful-firewall flows \(For Software Flows\) on page 42](#)  
[show services stateful-firewall flows brief on page 42](#)  
[show services stateful-firewall flows extensive on page 43](#)  
[show services stateful-firewall flows count on page 43](#)  
[show services stateful-firewall flows destination port on page 43](#)  
[show services stateful-firewall flows source port on page 43](#)  
[show services stateful-firewall flows \(Twice NAT\) on page 43](#)

**Output Fields** [Table 4 on page 41](#) lists the output fields for the **show services stateful-firewall flows** command. Output fields are listed in the approximate order in which they appear.

**Table 4: show services stateful-firewall flows Output Fields**

Field Name	Field Description
<b>Interface</b>	Name of the interface.
<b>Service set</b>	Name of a service set. Individual empty service sets are not displayed. If no service set has any flows, a flow table header is displayed for each service set.
<b>Flow Count</b>	Number of flows in a session.
<b>Flow or Flow Prot</b>	Protocol used for this flow.
<b>Source</b>	Source prefix of the flow in the format <i>source-prefix:port</i> . For ICMP flows, port information is not displayed.
<b>Dest</b>	Destination prefix of the flow. For ICMP flows, port information is not displayed.

Table 4: show services stateful-firewall flows Output Fields (*continued*)

Field Name	Field Description
State	Status of the flow: <ul style="list-style-type: none"> <li>• <b>Drop</b>—Drop all packets in the flow without response.</li> <li>• <b>Forward</b>—Forward the packet in the flow without looking at it.</li> <li>• <b>Reject</b>—Drop all packets in the flow with response.</li> <li>• <b>Watch</b>—Inspect packets in the flow.</li> </ul>
Dir	Direction of the flow: input (I) or output (O).
Frm count	Number of frames in the flow.

### Sample Output

**show services stateful-firewall flows** user@host> **show services stateful-firewall flows**  
Interface: ms-1/3/0, Service set: green

```
Flow
Prot    Source                Dest                State    Dir    Frm count
TCP     10.58.255.178:23    ->    10.59.16.100:4000 Forward  O
TCP     10.58.255.50:33005->    10.58.255.178:23 Forward  I          1
      Source NAT    10.58.255.50:33005->    10.59.16.100:4000
      Destin NAT   10.58.255.178:23    ->    0.0.0.0:4000
```

**show services stateful-firewall flows (For Software Flows)** When a service set includes software processing, the following output format is used for the software flows:

```
user@host> show services stateful-firewall flows
Interface: sp-0/1/0, Service set: dslite-svc-set2
Flow
TCP     200.200.200.2:80    ->    44.44.44.1:1025 Forward  O          219942
      NAT dest    44.44.44.1:1025    ->    20.20.1.4:1025
      Software    2001::2           ->    1001::1
TCP     20.20.1.2:1025    ->    200.200.200.2:80 Forward  I          110244
      NAT source   20.20.1.2:1025    ->    44.44.44.1:1024
      Software    2001::2           ->    1001::1
TCP     200.200.200.2:80    ->    44.44.44.1:1024 Forward  O          219140
      NAT dest    44.44.44.1:1024    ->    20.20.1.2:1025
      Software    2001::2           ->    1001::1
DS-LITE 2001::2           ->    1001::1 Forward  I          988729
TCP     200.200.200.2:80    ->    44.44.44.1:1026 Forward  O          218906
      NAT dest    44.44.44.1:1026    ->    20.20.1.3:1025
      Software    2001::2           ->    1001::1
TCP     20.20.1.3:1025    ->    200.200.200.2:80 Forward  I          110303
      NAT source   20.20.1.3:1025    ->    44.44.44.1:1026
      Software    2001::2           ->    1001::1
TCP     20.20.1.4:1025    ->    200.200.200.2:80 Forward  I          110944
      NAT source   20.20.1.4:1025    ->    44.44.44.1:1025
      Software    2001::2           ->    1001::1
```

**show services stateful-firewall flows brief** The output for the **show services stateful-firewall flows brief** command is identical to that for the **show services stateful-firewall flows** command. For sample output, see [show services stateful-firewall flows](#).

```

show services      user@host> show services stateful-firewall flows extensive
stateful-firewall flows
extensive          Interface: ms-0/3/0, Service set: ss_nat
Flow count
TCP                  16.1.0.1:2330 -> 16.49.0.1:21      State   Dir    Frm
count
8
  NAT source        16.1.0.1:2330 -> 16.41.0.1:2330
  NAT dest          16.49.0.1:21  -> 16.99.0.1:21
  Byte count: 455, TCP established, TCP window size: 57344
  TCP acknowledge: 3251737524, TCP tickle enabled, tcp_tickle: 0
  Flow role: Master, Timeout: 720
TCP                  16.99.0.1:21  -> 16.41.0.1:2330    State   Dir    Frm
count
5
  NAT source        16.99.0.1:21  -> 16.49.0.1:21
  NAT dest          16.41.0.1:2330 -> 16.1.0.1:2330
  Byte count: 480, TCP established, TCP window size: 57344
  TCP acknowledge: 463128048, TCP tickle enabled, tcp_tickle: 0
  Flow role: Responder, Timeout: 720

show services      user@host> show services stateful-firewall flows count
stateful-firewall flows
count              Interface      Service set      Flow Count
ms-1/3/0             green            2

show services      user@router> show services stateful-firewall flows destination-port 21
stateful-firewall flows
destination port  Interface: ms-0/3/0, Service set: svc_set_trust
Flow
Interface: ms-0/3/0, Service set: svc_set_untrust
Flow
TCP                  10.50.10.2:2143 -> 10.50.20.2:21    State   Dir    Frm count
Watch   0      0

show services      user@router> show services stateful-firewall flows source-port 2143
stateful-firewall flows
source port      Interface: ms-0/3/0, Service set: svc_set_trust
Flow
Interface: ms-0/3/0, Service set: svc_set_untrust
Flow
TCP                  10.50.10.2:2143 -> 10.50.20.2:21    State   Dir    Frm count
Watch   0      0

show services      user@router> show services stateful-firewall flows
stateful-firewall flows
(Twice NAT)      Flow
UDP                  40.0.0.8:23439 -> 80.0.0.1:16485    State   Dir    Frm count
NAT source          40.0.0.8:23439 -> 172.16.1.10:1028
NAT dest            80.0.0.1:16485 -> 192.16.1.10:22415
UDP                  192.16.1.10:22415 -> 172.16.1.10:1028    Watch   0      20
NAT source          192.16.1.10:22415 -> 80.0.0.1:16485
NAT dest            172.16.1.10:1028 -> 40.0.0.8:23439

```

## show services stateful-firewall statistics

<b>Syntax</b>	<pre>show services stateful-firewall statistics &lt;application-protocol <i>protocol</i>&gt; &lt;brief   detail   extensive   summary&gt; &lt;interface <i>interface-name</i>&gt; &lt;service-set <i>service-set</i>&gt;</pre>
<b>Release Information</b>	Command introduced in Junos OS Release 10.4.
<b>Description</b>	Display stateful firewall statistics.
<b>Options</b>	<p><b>none</b>—Display standard information about all stateful firewall statistics.</p> <p><b>brief   detail   extensive   summary</b>—(Optional) Display the specified level of output.</p> <p><b>interface <i>interface-name</i></b>—(Optional) Display information about a particular interface. On M Series and T Series routers, the <i>interface-name</i> can be <i>ms-fpc/pic/port</i> or <i>rspnumber</i>. On J Series routers, the <i>interface-name</i> is <i>ms-pim/O/port</i>.</p> <p><b>service-set <i>service-set</i></b>—(Optional) Display information about a particular service set.</p>
<b>Required Privilege Level</b>	view
<b>Related Documentation</b>	<ul style="list-style-type: none"> <li><a href="#">clear services stateful-firewall statistics on page 38</a></li> </ul>
<b>List of Sample Output</b>	<a href="#">show services stateful-firewall statistics extensive on page 47</a>
<b>Output Fields</b>	Table 5 on page 44 lists the output fields for the <b>show services stateful-firewall statistics</b> command. Output fields are listed in the approximate order in which they appear.

**Table 5: show services stateful-firewall statistics Output Fields**

Field Name	Field Description
<b>Interface</b>	Name of an adaptive services interface.
<b>Service set</b>	Name of a service set.
<b>New flows</b>	Rule match counters for new flows: <ul style="list-style-type: none"> <li><b>Accept</b>—New flows accepted.</li> <li><b>Discard</b>—New flows discarded.</li> <li><b>Reject</b>—New flows rejected.</li> </ul>
<b>Existing flows</b>	Rule match counters for existing flows: <ul style="list-style-type: none"> <li><b>Accept</b>—Match existing forward or watch flow.</li> <li><b>Discard</b>—Match existing discard flow.</li> <li><b>Reject</b>—Match existing reject flow.</li> </ul>

Table 5: show services stateful-firewall statistics Output Fields (*continued*)

Field Name	Field Description
<b>Drops</b>	<p>Drop counters:</p> <ul style="list-style-type: none"> <li>• <b>TCP SYN defense</b>—Packets dropped by SYN defender.</li> <li>• <b>NAT ports exhausted</b>—Hide mode. The router has no available Network Address Translation (NAT) ports for a given address or pool.</li> </ul>
<b>Errors</b>	<p>Total errors, categorized by protocol:</p> <ul style="list-style-type: none"> <li>• <b>IP</b>—Total IP version 4 errors.</li> <li>• <b>TCP</b>—Total Transmission Control Protocol (TCP) errors.</li> <li>• <b>UDP</b>—Total User Datagram Protocol (UDP) errors.</li> <li>• <b>ICMP</b>—Total Internet Control Message Protocol (ICMP) errors.</li> <li>• <b>Non-IP</b>—Total non-IPv4 errors.</li> </ul>
<b>IP Errors</b>	<p>IPv4 errors:</p> <ul style="list-style-type: none"> <li>• <b>IP packet length inconsistencies</b>—IP packet length does not match the Layer 2 reported length.</li> <li>• <b>Minimum IP header length check failures</b>—Minimum IP header length is 20 bytes. The received packet contains less than 20 bytes.</li> <li>• <b>Reassembled packet exceeds maximum IP length</b>—After fragment reassembly, the reassembled IP packet length exceeds 65,535.</li> <li>• <b>Illegal source address 0</b>—Source address is not a valid address. Invalid addresses are, loopback, broadcast, multicast, and reserved addresses. Source address 0, however, is allowed to support BOOTP and the destination address 0xffffffff.</li> <li>• <b>Illegal destination address 0</b>—Destination address is not a valid address. The address is reserved.</li> <li>• <b>TTL zero errors</b>—Received packet had a time-to-live (TTL) value of 0.</li> <li>• <b>IP protocol number 0 or 255</b>—IP protocol is 0 or 255.</li> <li>• <b>Land attack</b>—IP source address is the same as the destination address.</li> <li>• <b>Smurf attack</b>—Echo request is sent to a directed broadcast address.</li> <li>• <b>Non-IP packets</b>—Packet did not conform to the IP standard.</li> <li>• <b>IP option</b>—Packet dropped because of a nonallowed IP option.</li> <li>• <b>Non-IPv4 packets</b>—Packet was not IPv4. (Only IPv4 is supported.)</li> <li>• <b>Bad checksum</b>—Packet had an invalid IP checksum.</li> <li>• <b>Illegal IP fragment length</b>—Illegal fragment length. All fragments (other than the last fragment) must have a length that is a multiple of 8 bytes.</li> <li>• <b>IP fragment overlap</b>—Fragments have overlapping fragment offsets.</li> <li>• <b>IP fragment reassembly timeout</b>—Some of the fragments for an IP packet were not received in time, and the reassembly handler dropped partial fragments.</li> </ul>

Table 5: show services stateful-firewall statistics Output Fields (*continued*)

Field Name	Field Description
TCP Errors	<p>TCP protocol errors:</p> <ul style="list-style-type: none"> <li>• <b>TCP header length inconsistencies</b>—Minimum TCP header length is 20 bytes, and the IP packet received does not contain at least 20 bytes.</li> <li>• <b>Source or destination port number is zero</b>—TCP source or destination port is zero.</li> <li>• <b>Illegal sequence number, flags combination</b>—Dropped because of TCP errors, such as an illegal sequence number, which causes an illogical combination of flags to be set.</li> <li>• <b>SYN attack (multiple SYN messages seen for the same flow)</b>—Multiple SYN packets received for the same flow are treated as a SYN attack. The packets might be retransmitted SYN packets and therefore valid, but a large number is cause for concern.</li> <li>• <b>First packet not SYN</b>—First packets for a connection are not SYN packets. These packets might originate from previous connections or from someone performing an ACK/FIN scan.</li> <li>• <b>TCP port scan (Handshake, RST seen from server for SYN)</b>—In the case of a SYN defender, if an RST (reset) packet is received instead of a SYN/ACK message, someone is probably trying to scan the server. This behavior can result in false alarms if the RST packet is not combined with an intrusion detection service (IDS).</li> <li>• <b>Bad SYN cookie response</b>—SYN cookie generates a SYN/ACK message for all incoming SYN packets. If the ACK received for the SYN/ACK message does not match, this counter is incremented.</li> </ul>
UDP Errors	<p>UDP protocol errors:</p> <ul style="list-style-type: none"> <li>• <b>IP data length less than minimum UDP header length (8 bytes)</b>—Minimum UDP header length is 8 bytes. The received IP packets contain less than 8 bytes.</li> <li>• <b>Source or destination port is zero</b>—UDP source or destination port is 0.</li> <li>• <b>UDP port scan (ICMP error seen for UDP flow)</b>—ICMP error is received for a UDP flow. This could be a genuine UDP flow, but it is counted as an error.</li> </ul>
ICMP Errors	<p>ICMP protocol errors:</p> <ul style="list-style-type: none"> <li>• <b>IP data length less than minimum ICMP header length (8 bytes)</b>—ICMP header length is 8 bytes. This counter is incremented when received IP packets contain less than 8 bytes.</li> <li>• <b>ICMP error length inconsistencies</b>—Minimum length of an ICMP error packet is 48 bytes, and the maximum length is 576 bytes. This counter is incremented when the received ICMP error falls outside this range.</li> <li>• <b>Ping duplicate sequence number</b>—Received ping packet has a duplicate sequence number.</li> <li>• <b>Ping mismatched sequence number</b>—Received ping packet has a mismatched sequence number.</li> </ul>

## Sample Output

```

show services stateful-firewall statistics extensive
user@host> show services stateful-firewall statistics extensive
Interface: ms-1/3/0
Service set: interface-svc-set
New flows:
  Accept: 907, Discard: 0, Reject: 0
Existing flows:
  Accept: 3535, Discard: 0, Reject: 0
Drops:
  IP option: 0, TCP SYN defense: 0
  NAT ports exhausted: 0
Errors:
  IP: 0, TCP: 0
  UDP: 0, ICMP: 0
  Non-IP packets: 0, ALG: 0
IP errors:
  IP packet length inconsistencies: 0
  Minimum IP header length check failures: 0
  Reassembled packet exceeds maximum IP length: 0
  Illegal source address: 0
  Illegal destination address: 0
  TTL zero errors: 0, IP protocol number 0 or 255: 0
  Land attack: 0, Smurf attack: 0
  Non IP packets: 0, IP option: 0
  Non-IPv4 packets: 0, Bad checksum: 0
  Illegal IP fragment length: 0
  IP fragment overlap: 0
  IP fragment reassembly timeout: 0
TCP errors:
  TCP header length inconsistencies: 0
  Source or destination port number is zero: 0
  Illegal sequence number, flags combination: 0
  SYN attack (multiple SYNs seen for the same flow): 0
  First packet not SYN: 0
  TCP port scan (Handshake, RST seen from server for SYN): 0
  Bad SYN cookie response: 0
UDP errors:
  IP data length less than minimum UDP header length (8 bytes): 0
  Source or destination port is zero: 0
  UDP port scan (ICMP error seen for UDP flow): 0
ICMP errors:
  IP data length less than minimum ICMP header length (8 bytes): 0
  ICMP error length inconsistencies: 0
  Ping duplicate sequence number: 0
  Ping mismatched sequence number: 0
ALG drops:
  BOOTP: 0, DCE-RPC: 0, DCE-RPC portmap: 0
  DNS: 0, Exec: 0, FTP: 0
  ICMP: 0
  Login: 0, Netbios: 0, Netshow: 0
  RPC: 0, RPC portmap: 0
  RTSP: 0, Shell: 0
  SNMP: 0, Sqlnet: 0, TFTP: 0
  Traceroute: 0

```



## PART 4

# Index

- [Index on page 51](#)



# Index

## Symbols

#, comments in configuration statements.....	x
( ), in syntax descriptions.....	x
< >, in syntax descriptions.....	x
[ ], in configuration statements.....	x
{ }, in configuration statements.....	x
(pipe), in syntax descriptions.....	x

## A

allow-ip-options statement.....	21
usage guidelines.....	9
application-sets statement	
stateful firewall.....	22
usage guidelines.....	8
applications statement	
application-level gateways.....	22
stateful firewall.....	22
usage guidelines.....	8

## B

braces, in configuration statements.....	x
brackets	
angle, in syntax descriptions.....	x
square, in configuration statements.....	x

## C

clear services stateful-firewall flows	
command.....	36
clear services stateful-firewall statistics	
command.....	38
comments, in configuration statements.....	x
conventions	
text and syntax.....	ix
curly braces, in configuration statements.....	x
customer support.....	xi
contacting JTAC.....	xi

## D

destination-address statement	
stateful firewall.....	23
usage guidelines.....	8

destination-address-range statement	
stateful firewall.....	23
usage guidelines.....	8
destination-prefix-list statement	
stateful firewall.....	24
usage guidelines.....	8
documentation	
comments on.....	xi

## F

font conventions.....	ix
from statement	
stateful firewall.....	25
usage guidelines.....	7, 8

## M

manuals	
comments on.....	xi
match-direction statement	
stateful firewall.....	25
usage guidelines.....	8

## P

parentheses, in syntax descriptions.....	x
--	---

## R

rule statement	
stateful firewall.....	26
usage guidelines.....	7
rule-set statement	
stateful firewall.....	27
usage guidelines.....	10

## S

services statement	
stateful firewall.....	27
show services stateful-firewall flows	
command.....	39
show services stateful-firewall statistics	
command.....	44
source-address statement	
stateful firewall.....	28
usage guidelines.....	8
source-address-range statement	
stateful firewall.....	28
usage guidelines.....	8
source-prefix-list statement	
stateful firewall.....	29
usage guidelines.....	8

stateful firewall	
action statements.....	9
applications.....	8
example configuration.....	17
flows	
clearing.....	36
displaying.....	39
match conditions.....	8
rules.....	10
statistics	
clearing.....	38
displaying.....	44
support, technical See technical support	
syntax conventions.....	ix
syslog statement	
stateful firewall.....	29
usage guidelines.....	9
 T	
technical support	
contacting JTAC.....	xi
term statement	
stateful firewall.....	30
usage guidelines.....	7
then statement	
stateful firewall.....	31
usage guidelines.....	7, 9