

clear dhcp relay statistics

Syntax	clear dhcp relay statistics <logical-system <i>logical-system-name</i> > <routing-instance <i>routing-instance-name</i> >
Release Information	Command introduced in JUNOS Release 8.3.
Description	Clear all Dynamic Host Configuration Protocol (DHCP) relay statistics.
Options	<p>logical-system <i>logical-system-name</i>—(Optional) Perform this operation on the specified logical system. If you do not specify a logical system name, statistics are cleared for the default logical system.</p> <p>routing-instance <i>routing-instance-name</i>—(Optional) Perform this operation on the specified routing instance. If you do not specify a routing instance name, statistics are cleared for the default routing instance.</p>
Required Privilege Level	view
List of Sample Output	clear dhcp relay statistics on page 1
Output Fields	See show dhcp relay statistics for an explanation of output fields.
clear dhcp relay statistics	<p>The following sample output displays the DHCP relay statistics before and after the clear dhcp relay statistics command is issued.</p> <pre>user@host> show dhcp relay statistics Packets dropped: Total 0 Messages received: BOOTREQUEST 116 DHCPDECLINE 0 DHCPDISCOVER 11 DHCPINFORM 0 DHCPRELEASE 0 DHCPREQUEST 105 Messages sent: BOOTREPLY 44 DHCPOFFER 11 DHCPACK 11 DHCPNAK 11 user@host> clear dhcp relay statistics user@host> show dhcp relay statistics Packets dropped: Total 0 Messages received: BOOTREQUEST 0 DHCPDECLINE 0 DHCPDISCOVER 0 DHCPINFORM 0 DHCPRELEASE 0</pre>

DHCPREQUEST	0
Messages sent:	
BOOTREPLY	0
DHCPOFFER	0
DHCPACK	0
DHCPNAK	0