

## request virtual-chassis recycle

---

**Syntax**    request virtual-chassis recycle member-id *member-id*

**Release Information**    Command introduced in JUNOS Release 9.0 for EX-series switches.

**Description**    Make a previously used member ID available for reassignment.

When you remove a member switch from the Virtual Chassis configuration, the master reserves that member ID. To make the member ID available for reassignment, you must use this command.



**NOTE:** You can run this command from the Virtual Chassis master only.

---

**Options**    member-id *member-id*—Specify the member id that you want to make available for reassignment to a different member switch.

**Required Privilege Level**    system-control

**Related Topics**    ■ request virtual-chassis renumber  
                         ■ Replacing a Member Switch of a Virtual Chassis Configuration (CLI Procedure)

**List of Sample Output**    request virtual-chassis recycle member-id 3 on page 1

**request virtual-chassis  
recycle member-id 3**    user@host> request virtual-chassis recycle member-id 3

---

Published: 2009-06-26