

## aggregated-devices

---

**Syntax**    aggregated-devices {  
              ethernet {  
                  device-count *number*;  
              }  
          }

**Hierarchy Level**    [edit chassis]

**Release Information**    Statement introduced in JUNOS Release 9.0 for EX-series switches.

**Description**    Configure properties for aggregated devices on the switch.

                  The statements are explained separately.

**Default**    Disabled.

**Required Privilege Level**    interface—To view this statement in the configuration.  
                                  interface-control—To add this statement to the configuration.

- Related Topics**
- *JUNOS Network System Basics Configuration Guide* at <http://www.juniper.net/techpubs/software/junos/junos90/index.html>
  - Example: Configuring Aggregated Ethernet High-Speed Uplinks Between a Virtual Chassis Access Switch and a Virtual Chassis Distribution Switch
  - Configuring Aggregated Ethernet Interfaces (CLI Procedure)
  - Understanding Aggregated Ethernet Interfaces and LACP

