

## authentication-server

---

<b>Syntax</b>	authentication-server [ <i>server-addresses</i> ];
<b>Hierarchy Level</b>	[edit access profile <i>profile-name</i> radius]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.0 for EX-series switches.
<b>Description</b>	Configure the Remote Authentication Dial-In User Service (RADIUS) server for authentication. To configure multiple RADIUS servers, include multiple server addresses. The servers are tried in order and in a round-robin fashion until a valid response is received from one of the servers or until all the configured retry limits are reached.
<b>Default</b>	Not enabled
<b>Options</b>	<i>server-addresses</i> —Configure one or more RADIUS server addresses.
<b>Required Privilege Level</b>	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Example: Connecting a RADIUS Server for 802.1X to an EX-series Switch</li><li>■ show network-access aaa statistics authentication</li><li>■ Example: Connecting a RADIUS Server for 802.1X to an EX-series Switch</li></ul>

