

chassis

Syntax chassis {
 aggregated-devices {
 ethernet {
 device-count *number*;
 }
 }
 }
 }

Hierarchy Level [edit]

Release Information Statement introduced in JUNOS Release 9.0 for EX-series switches.

Description Configure chassis-specific properties. Most standard JUNOS configuration statements are available in the JUNOS for EX-series software. This page lists JUNOS statements that you commonly use when configuring EX-series software as well as statements added to support only EX-series switches.

The statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

Related Topics ■ *JUNOS Network System Basics Configuration Guide* at
 <http://www.juniper.net/techpubs/software/junos/junos90>

