

domain-name

Syntax	<code>domain-name <i>domain-name-string</i>;</code>
Hierarchy Level	<code>[edit forwarding-options dhcp-relay authentication username-include],</code> <code>[edit forwarding-options dhcp-relay group <i>group-name</i> authentication username-include],</code> <code>[edit logical-systems <i>logical-system-name</i> forwarding-options dhcp-relay authentication</code> <code>username-include],</code> <code>[edit logical-systems <i>logical-system-name</i> forwarding-options dhcp-relay group <i>group-name</i></code> <code>authentication username-include],</code> <code>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i></code> <code>forwarding-options dhcp-relay authentication username-include],</code> <code>[edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i></code> <code>forwarding-options dhcp-relay group <i>group-name</i> authentication username-include],</code> <code>[edit routing-instances <i>routing-instance-name</i> forwarding-options dhcp-relay authentication</code> <code>username-include],</code> <code>[edit routing-instances <i>routing-instance-name</i> forwarding-options dhcp-relay group</code> <code><i>group-name</i> authentication username-include]</code>
Release Information	Statement introduced in JUNOS Release 9.1.
Description	Specify the domain name that is concatenated with the username during the subscriber authentication process.
Options	<i>domain-name-string</i> —The domain name formatted string.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	■ Using External AAA Authentication Services with DHCP

