

ethernet-port-type-virtual

| | |
|---------------------------------|--|
| Syntax | ethernet-port-type-virtual; |
| Hierarchy Level | [edit access profile <i>profile-name</i> radius options] |
| Release Information | Statement introduced in JUNOS Release 9.1. |
| Description | Specify the physical port type the router uses to authenticate clients. The port type is passed in RADIUS attribute 61 (NAS-Port-Type). This statement specifies a port type of <i>virtual</i> ; by default the router passes a port type of ethernet in RADIUS attribute 61. |
| Required Privilege Level | admin—To view this statement in the configuration. admin-control—To add this statement to the configuration. |
| Related Topics | ■ Configuring RADIUS Server Parameters for Subscriber Access |

