

forwarding-class

Syntax	<pre>forwarding-class <i>class-name</i> { loss-priority <i>level</i> { code-points [<i>aliases</i>] [<i>6-bit-patterns</i>]; } }</pre>
Hierarchy Level	[edit class-of-service classifiers (dscp ieee-802.1 inet-precedence) <i>classifier-name</i>], [edit class-of-service interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit class-of-service rewrite-rules] (dscp ieee-802.1 inet-precedence) <i>rewrite-name</i>], [edit class-of-service scheduler-maps <i>map-name</i>]
Release Information	Statement introduced in JUNOS Release 9.0 for EX-series switches.
Description	Define forwarding class name and option values.
Options	<p><i>class-name</i> —Name of the forwarding class.</p> <p>The remaining statements are explained separately.</p>
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ Example: Configuring CoS on EX-series Switches■ Defining CoS Forwarding Classes (CLI Procedure) or Defining CoS Forwarding Classes (J-Web Procedure)■ Understanding CoS Forwarding Classes

