

## grace-period

---

<b>Syntax</b>	<code>grace-period seconds;</code>
<b>Hierarchy Level</b>	[edit access address-assignment pool <i>pool-name</i> family inet dhcp-attributes]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.0.
<b>Description</b>	Configure the amount of time that the client retains the address lease after the lease expires. The address cannot be reassigned to another client during the grace period.
<b>Options</b>	<code>seconds</code> —Number of seconds the lease is retained. <b>Range:</b> 0 through 4,294,967,295 seconds <b>Default:</b> 0 (no grace period)
<b>Required Privilege Level</b>	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.
<b>Related Topics</b>	■ <a href="#">Configuring Address-Assignment Pools</a>

