

## group-name

---

**Syntax**    group-name *name* {  
              interface *interface-name* <primary>;  
              interface *interface-name*;  
              }

**Hierarchy Level**    [edit ethernet-switching-options redundant-trunk-group]

**Release Information**    Statement introduced in JUNOS Release 9.0 for EX-series switches.

**Description**    Create a redundant trunk group.

**Options**    *name*—The name of the redundant trunk group. The group name must start with a letter and can consist of letters, numbers, dashes, and underscores.

The remaining options are explained separately.

**Required Privilege Level**    routing—To view this statement in the configuration.  
                                  routing-control—To add this statement to the configuration.

**Related Topics**    ■    Example: Configuring Redundant Trunk Links for Faster Recovery  
                          ■    Understanding Redundant Trunk Links on EX-series Switches

