

## interval

---

<b>Syntax</b>	interval <i>minutes</i> ;
<b>Hierarchy Level</b>	[edit poe interface (all   <i>interface-name</i> ) telemetries]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.0 for EX-series switches.
<b>Description</b>	Modify the interval for logging telemetries if you are monitoring the per-port power consumption for PoE interfaces.
<b>Options</b>	<i>minutes</i> —Frequency of logging. <b>Range:</b> 1 through 30 minutes <b>Default:</b> 5 minutes
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Example: Configuring PoE Interfaces on an EX-series Switch</li><li>■ Example: Configuring PoE Interfaces with Different Priorities on an EX-series Switch</li><li>■ Configuring PoE (CLI Procedure)</li><li>■ Configuring PoE (J-Web Procedure)</li><li>■ PoE and EX-series Switches Overview</li></ul>

