

level

| | |
|---------------------------------|--|
| Syntax | level <i>level</i> ; |
| Hierarchy Level | [edit ethernet-switching-options storm-control interface (all <i>interface-name</i>)] |
| Release Information | Statement introduced in JUNOS Release 9.1 for EX-series switches. |
| Description | For interfaces configured for storm control, configure the storm control level as a percentage of the combined broadcast and unknown unicast streams. The level set to 100 % means no traffic storm control. |
| Default | When storm control is enabled on an interface, the storm control level is 80 %. |
| Options | <i>level</i> —Percentage of the combined broadcast and unknown unicast streams. Range: 0 through 100 % Default: 80 % The remaining statements are explained separately. |
| Required Privilege Level | routing—To view this statement in the configuration. routing-control—To add this statement to the configuration. |
| Related Topics | <ul style="list-style-type: none">■ Example: Configuring Storm Control to Prevent Network Outages on EX-series Switches■ Understanding Storm Control on EX-series Switches |

