

## no-reauthentication

---

<b>Syntax</b>	no-reauthentication;
<b>Hierarchy Level</b>	[edit protocols dot1x authenticator interface (all   [ <i>interface-names</i> ])]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.0 for EX-series switches.
<b>Description</b>	For 802.1X authentication, disables reauthentication.
<b>Default</b>	Not disabled
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Configuring 802.1X Authentication (CLI Procedure)</li><li>■ Configuring 802.1X Authentication (J-Web Procedure)</li><li>■ Understanding 802.1X Authentication on EX-series Switches</li></ul>

