

## overrides

---

**Syntax**    overrides {  
             always-write-giaddr;  
             always-write-option-82;  
             client-discover-match;  
             interface-client-limit *number*;  
             layer2-unicast-replies;  
             no-arp;  
             trust-option-82;  
             disable-relay;  
          }

**Hierarchy Level**    [edit forwarding-options dhcp-relay],  
                         [edit forwarding-options dhcp-relay group *group-name*],  
                         [edit logical-systems *logical-system-name* forwarding-options dhcp-relay],  
                         [edit logical-systems *logical-system-name* forwarding-options dhcp-relay group *group-name*],  
                         [edit logical-systems *logical-system-name* routing-instances *routing-instance-name*  
                         forwarding-options dhcp-relay],  
                         [edit logical-systems *logical-system-name* routing-instances *routing-instance-name*  
                         forwarding-options dhcp-relay group *group-name*],  
                         [edit routing-instances *routing-instance-name* forwarding-options dhcp-relay],  
                         [edit routing-instances *routing-instance-name* forwarding-options dhcp-relay group  
                         *group-name*]

**Release Information**    Statement introduced in JUNOS Release 8.3.

**Description**    Override the default configuration settings for the extended DHCP relay agent. Specifying the **overrides** statement with no subordinate statements removes all DHCP relay agent overrides at that hierarchy level.

To override global DHCP relay agent configuration options, include the **overrides** statement and its subordinate statements at the [edit forwarding-options dhcp-relay] hierarchy level. To override DHCP relay agent configuration options for a named group of interfaces, include the statements at the [edit forwarding-options dhcp-relay group *group-name*] hierarchy level.

The statements are explained separately.

**Required Privilege Level**    interface—To view this statement in the configuration.  
                         interface-control—To add this statement to the configuration.

**Related Topics**    ■    Extended DHCP Relay Agent Overview

