

poe

Syntax poe {
 guard-band *watts*;
 interface (all | *interface-name*) {
 disable;
 maximum-power *watts*;
 priority *value*;
 telemetries {
 disable;
 duration *hours*;
 interval *minutes*;
 }
 }
 management *type*;
 }

Hierarchy Level [edit]

Release Information Statement introduced in JUNOS Release 9.0 for EX-series switches.

Description Configure PoE options.

 The statements are explained separately.

Default Specified interfaces have PoE capabilities enabled by default.

Required Privilege Level router—To view this statement in the configuration.
 router-control—To add this statement to the configuration.

Related Topics ■ Example: Configuring PoE Interfaces on an EX-series Switch
 ■ Example: Configuring PoE Interfaces with Different Priorities on an EX-series Switch
 ■ Configuring PoE (CLI Procedure)
 ■ Configuring PoE (J-Web Procedure)
 ■ PoE and EX-series Switches Overview

