

## port

---

<b>Syntax</b>	<code>port <i>port-number</i>;</code>
<b>Hierarchy Level</b>	[edit access radius-server <i>server-address</i> ], [edit access profile <i>profile-name</i> radius-server <i>server-address</i> ]
<b>Release Information</b>	Statement introduced before JUNOS Release 7.4.
<b>Description</b>	Configure the port number on which to contact the RADIUS server.
<b>Options</b>	<i>port-number</i> —Port number on which to contact the RADIUS server. <b>Default:</b> 1812 (as specified in RFC 2865)
<b>Required Privilege Level</b>	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Router Interaction with RADIUS Servers Overview</li><li>■ Configuring Authentication and Accounting Parameters for Subscriber Access</li></ul>

