

retry

Syntax	<code>retry attempts;</code>
Hierarchy Level	[edit access radius-server <i>server-address</i>], [edit access profile <i>profile-name</i> radius-server <i>server-address</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Number of times that the router is allowed to attempt to contact a RADIUS authentication or accounting server.
Options	<i>attempts</i> —Number of times that the router is allowed to attempt to contact a RADIUS server. Range: 1 through 10 Default: 3
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ Configuring Authentication and Accounting Parameters for Subscriber Access■ Router Interaction with RADIUS Servers Overview■ timeout

