

server-group

Syntax	<pre>server-group { server-group-name { server-ip-address; } }</pre>
Hierarchy Level	[edit forwarding-options dhcp-relay], [edit logical-systems <i>logical-system-name</i> forwarding-options dhcp-relay], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> forwarding-options dhcp-relay], [edit routing-instances <i>routing-instance-name</i> forwarding-options dhcp-relay]
Release Information	Statement introduced in JUNOS Release 8.3.
Description	Specify the name of a group of DHCP server addresses for use by the extended DHCP relay agent.
Options	<p><i>server-group-name</i>—Name of the group of DHCP server addresses.</p> <p><i>server-ip-address</i>—IP address of the DHCP server belonging to this named server group. You can configure a maximum of five IP addresses per named server group.</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	■ Extended DHCP Relay Agent Overview

