

Configuring Accounting for Mobile IP Subscribers

You can configure time-based accounting to track the subscriber sessions of Mobile IP subscribers.

To configure Mobile IP accounting:

1. Configure the IP address for the RADIUS accounting server.

```
[edit access profile mip-win4]
user@host# set radius accounting server 192.168.20.5
```

2. Specify RADIUS as the accounting method for Mobile IP subscribers.

```
[edit access profile mip-win4 accounting]
user@host# set order radius
```

3. Specify time-based accounting for the access profile used for the subscriber.

```
[edit access profile mip-win4 accounting]
user@host# set statistics time
```

- Related Topics**
- Configuring Mobile IP
 - Specifying the Authentication and Accounting Methods for Subscriber Access
 - Configuring How Accounting Statistics Are Collected for Subscriber Access
 - Configuring RADIUS Server Parameters for Subscriber Access
 - order
 - radius accounting server
 - statistics

