

Getting Help on JCS Commands

The JCS management module CLI includes a **help** command you can use to get a list of available commands or to get help on individual commands.

- For a list of available commands, enter the **help** command. For example:

```
system> help

? - Display commands
accseccfg - View/edit account security config
advfailover - View/edit advanced failover mode
alarm - Manage Telco System Management alarm(s)
alertcfg - Displays/Configures the global remote alert systems
alertentries - View/edit remote alarm recipients
baydata - View/edit Blade Bay Data string
...
```

- For help on individual commands, enter **command -help**, where *command* is the name of the command for which you want help. For example:

```
system> clock -help

usage:
  clock [-options]
options:
  -d      - date (mm/dd/yyyy)
  -t      - time (hh:mm:ss)
  -g      - GMT offset
  -dst    - daylight savings time (on|off|special case)
For a GMT offset of +2:00, use one of the following values for dst:
  ee      - Eastern Europe
  gtb     - Great Britain
  egt     - Egypt
  fle     - Finland
  off
For a GMT offset of +10:00, use one of the following values for dst:
  ea      - Eastern Australia
  tas     - Tasmania
  vlad    - Vladivostok
  off
For a GMT offset in set {-9:00, -8:00, -7:00, -6:00, -5:00}, use one of
the
following values for dst:
  uc      - USA and Canada
  other   - Other locations
  off
For a GMT offset of -4:00, use one of the following values for dst:
  can     - Canada
  other   - Other locations
  off
```

- You can also use the **?** or **-h** shortcuts to get help. For example:

```
system> clock -h

system> clock ?
```

Table 1 on page 2 shows syntax conventions used in `help` command output.

Table 1: Syntax Conventions for JCS Management Module CLI Help

Item	Description
[]	Used for indexing (by slot (bay) number)
< >	Denotes a variable
{ }	Denotes an optional argument
	Denotes a choice

- Related Topics**
- JCS Management Module CLI Overview
 - Logging In to the JCS Management Module CLI
 - Setting the JCS Management Module Command Target
 - Exiting the JCS Management Module CLI
 - `help`