

## Exiting the JCS Management Module CLI

---

When you have finished entering JCS management module CLI commands, use the `exit` command to exit the CLI and terminate the session.

```
system> exit
```

```
username:
```

- Related Topics**
- JCS Management Module CLI Overview
  - Logging In to the JCS Management Module CLI
  - Getting Help on JCS Commands
  - Setting the JCS Management Module Command Target
  - `exit`

