

## Example: Minimum PPPoE Dynamic Profile

---

This example shows the minimum configuration for a dynamic profile that is used for static PPPoE interfaces. The configuration must include the `interface pp0` stanza.

```
ppp-profile-1 {  
  interfaces {  
    pp0 {  
      unit "$junos-interface-unit";  
    }  
  }  
}
```

- Related Topics**
- [Dynamic Profile Attachment to PPP Subscriber Interfaces Overview](#)
  - [Attaching Dynamic Profiles to PPP Subscriber Interfaces](#)

