

show dot1x firewall

Syntax	show dot1x firewall <interface <i>interface-name</i> >
Release Information	Command introduced in JUNOS Release 9.5 for EX-series switches.
Description	Displays information about the firewall filters for each user or nonresponsive host that is authenticated on each 802.1x-enabled interface that is configured for multiple supplicants. For example, if the firewall filter is configured with a term for counters, the command shows the specified count for each user.
Options	interface <i>interface-names</i> —(Optional) Display information for the specified interface.
Required Privilege Level	view
Related Topics	<ul style="list-style-type: none">■ clear dot1x■ Example: Applying Firewall Filters to Multiple Supplicants on Interfaces Enabled for 802.1X or MAC RADIUS Authentication
List of Sample Output	show dot1x firewall on page 1
Output Fields	Output fields include any action modifier that is specified in firewall filters, with the exception of policers. Policers are not supported in the terms of the internally generated dynamic firewall filters that are created when multiple supplicants authenticate on 802.1X-enabled interfaces.
show dot1x firewall	<pre>user@switch> show dot1x firewall Filter: dot1x-filter-ge-0/0/3 Counters counter1_dot1x_ge-0/0/3_user1 342 counter1_dot1x_ge-0/0/3_user2 857</pre>

