

accounting

Syntax	<pre>accounting { destination-class-usage; source-class-usage { <i>direction</i>; } }</pre>
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Enable IP packet counters on an interface. The statements are explained separately.
Usage Guidelines	See Enabling Source Class and Destination Class Usage.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

