

adjacency-timer

Syntax	adjacency-timer <i>seconds</i> ;
Hierarchy Level	[edit protocols ancp], [edit protocols ancp neighbor]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Specify the interval between adjacency messages sent to ANCP adjacency peer (access node) for all peers or a specific peer.
Options	<i>seconds</i> —Number of seconds between adjacency messages. Range: 1 through 25 seconds Default: 10 seconds
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ Configuring ANCP■ Specifying the Interval Between ANCP Adjacency Messages■ Configuring ANCP Neighbors

