

aggregated-devices

Syntax aggregated-devices {
 ethernet {
 device-count *number*;
 }
 }

Hierarchy Level [edit chassis]

Release Information Statement introduced in JUNOS Release 9.0 for EX-series switches.

Description Configure properties for aggregated devices on the switch.

 The statements are explained separately.

Default Disabled.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

- Related Topics**
- *JUNOS Network System Basics Configuration Guide* at <http://www.juniper.net/techpubs/software/junos/junos90/index.html>
 - Example: Configuring Aggregated Ethernet High-Speed Uplinks Between a Virtual Chassis Access Switch and a Virtual Chassis Distribution Switch
 - Configuring Aggregated Ethernet Interfaces (CLI Procedure)
 - Understanding Aggregated Ethernet Interfaces and LACP

