

## authenticate

---

<b>Syntax</b>	authenticate { order (aaa   local); }
<b>Hierarchy Level</b>	[edit logical-systems <i>logical-system-name</i> services mobile-ip], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instances-name</i> services mobile-ip], [edit routing-instances <i>routing-instances-name</i> services mobile-ip], [edit services mobile-ip]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.3. Support at the [edit logical-systems <i>logical-system-name</i> services mobile-ip], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instances-name</i> services mobile-ip], and [edit routing-instances <i>routing-instances-name</i> services mobile-ip] hierarchy levels added in JUNOS Release 9.5.
<b>Description</b>	Define the authentication method performed for Mobile IP.
<b>Options</b>	The remaining statement is explained separately.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Configuring Mobile IP</li><li>■ Configuring the Access Type for Mobile IP</li></ul>

