

authentication-order

Syntax authentication-order [*authentication-methods*];

Hierarchy Level [edit access profile *profile-name*]

Release Information Statement introduced before JUNOS Release 7.4.

Description Set the order in which the JUNOS software tries different authentication methods when verifying that a client can access the router. For each login attempt, the software tries the authentication methods in order, from first to last.

Options radius—Verify the client using RADIUS authentication services.

password—Verify the client using the information configured at the [edit access profile *profile-name* client *client-name*] hierarchy level.



NOTE: The `password` keyword is not supported by the subscriber access management feature.

Required Privilege Level admin—To view this statement in the configuration.
admin-control—To add this statement to the configuration.

Related Topics ■ Specifying the Authentication and Accounting Methods for Subscriber Access

