

auto-reconnect

Syntax	auto-reconnect <i>seconds</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> pppoe-options], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> pppoe-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For J-series Services Routers with PPP over Ethernet interfaces, configure the amount of time to wait before reconnecting after a session has terminated.
Options	<i>seconds</i> —Time to wait before reconnecting after a session has terminated. Range: 0 through 4,294,967,295 seconds Default: 0 (immediately)
Usage Guidelines	See Configuring PPPoE.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>J-series Services Router Basic LAN and WAN Access Configuration Guide</i>

