

bandwidth

| | |
|---------------------------------|---|
| Syntax | bandwidth <i>bandwidth</i> ; |
| Hierarchy Level | [edit ethernet-switching-options storm-control interface (all <i>interface-name</i>)] |
| Release Information | Statement introduced in JUNOS Release 9.5 for EX-series switches. |
| Description | For interfaces configured for storm control, configure the storm control level as the bandwidth in kilobits per second of the combined broadcast and unknown unicast streams. |
| Default | None. |
| Options | bandwith—Traffic rate in kilobits per second of the combined broadcast and unknown unicast streams. Range: 100 through 10000000 Kbps Default: None |
| Required Privilege Level | routing—To view this statement in the configuration. routing-control—To add this statement to the configuration. |
| Related Topics | <ul style="list-style-type: none">■ Example: Configuring Storm Control to Prevent Network Outages on EX-series Switches■ Understanding Storm Control on EX-series Switches |

