

broadcast

Syntax	<code>broadcast forwarding-class-name;</code>
Hierarchy Level	[edit class-of-service multi-destination family ethernet]
Release Information	Statement introduced in JUNOS Release 9.5 for EX-series switches.
Description	Specify the forwarding class for the broadcast traffic belonging to the Ethernet family.
Options	<p><i>forwarding-class-name</i>—Name of the forwarding class:</p> <ul style="list-style-type: none">■ <i>mcast-af</i>—Default forwarding class for assured forwarding of multicast traffic.■ <i>mcast-be</i>—Default best-effort forwarding class for multicast traffic.■ <i>mcast-ef</i>—Default forwarding class for expedited forwarding of multicast traffic.
Required Privilege Level	<p>routing—To view this statement in the configuration.</p> <p>routing-control—To add this statement to the configuration.</p>
Related Topics	<ul style="list-style-type: none">■ Understanding CoS Schedulers■ Understanding CoS Forwarding Classes■ Understanding CoS Classifiers

