

## burst-size-limit (ethernet)

---

<b>Syntax</b>	burst-size-limit <i>bytes</i> ;
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> gigether-options ethernet-switch-profile ethernet-policer-profile policer <i>cos-policer-name</i> <a href="#">[Unresolved xref]</a> ], [edit interfaces <i>interface-name</i> gigether-options ethernet-switch-profile ethernet-policer-profile policer <i>cos-policer-name</i> <a href="#">[Unresolved xref]</a> ]
<b>Release Information</b>	Statement introduced before JUNOS Release 7.4.
<b>Description</b>	Define a policer to apply to nonpremium traffic.
<b>Options</b>	<i>bytes</i> —Burst length. <b>Range:</b> 1500 through 100,000,000 bytes
<b>Usage Guidelines</b>	See Configuring Gigabit Ethernet Policers.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Topics</b>	bandwidth-limit (ethernet)

