

delimiter

Syntax delimiter *delimiter-character*;

Hierarchy Level [edit logical-systems *logical-system-name* routing-instances *routing-instance-name* system services dhcp-local-server authentication username-include],
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name* system services dhcp-local-server group *group-name* authentication username-include],
[edit logical-systems *logical-system-name* system services dhcp-local-server authentication username-include],
[edit logical-systems *logical-system-name* system services dhcp-local-server group *group-name* authentication username-include],
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name* system services dhcp-local-server authentication username-include],
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name* system services dhcp-local-server group *group-name* authentication username-include],
[edit routing-instances *routing-instance-name* system services dhcp-local-server authentication username-include],
[edit routing-instances *routing-instance-name* system services dhcp-local-server group *group-name* authentication username-include],
[edit system services dhcp-local-server authentication username-include],
[edit system services dhcp-local-server group *group-name* authentication username-include]

Release Information Statement introduced in JUNOS Release 9.1.

Description Specify the character used as the delimiter between the concatenated components of the username. The semicolon (;) cannot be used as a delimiter.

Required Privilege Level system—To view this statement in the configuration.
system-control—To add this statement to the configuration.

Related Topics ■ Using External AAA Authentication Services with DHCP

