

## destination-class-usage

---

<b>Syntax</b>	destination-class-usage;
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet accounting], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet accounting]
<b>Release Information</b>	Statement introduced before JUNOS Release 7.4.
<b>Description</b>	Enable packet counters on an interface that count packets that arrive from specific customers and are destined for specific prefixes on the provider core router.
<b>Usage Guidelines</b>	See Enabling Source Class and Destination Class Usage.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Topics</b>	accounting, source-class-usage

