

disable

Syntax	disable;
Hierarchy Level	[edit poe interface (all <i>interface-name</i>)], [edit poe interface (all <i>interface-name</i>) telemetries]
Release Information	Statement introduced in JUNOS Release 9.0 for EX-series switches.
Description	<p>Disables the PoE capabilities of this port. The port operates as a standard network access port. If the disable statement is specified after the telemetries statement, it disables the logging of PoE power consumption for this port.</p> <p>To disable the monitoring and retain the stored configuration values for interval and duration for possible future use, you can specify the disable substatement in the stanza for telemetries.</p>
Default	The PoE capabilities are automatically enabled when a PoE interface is set. If the telemetries statement is specified, monitoring of PoE per-port power consumption is enabled.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ Example: Configuring PoE Interfaces on an EX-series Switch■ Example: Configuring PoE Interfaces with Different Priorities on an EX-series Switch■ Configuring PoE (CLI Procedure)■ Configuring PoE (J-Web Procedure)■ PoE and EX-series Switches Overview

