

## disable

---

**Syntax**    disable;

**Hierarchy Level**    [edit protocols mstp],  
[edit protocols mstp interface *interface-name*],  
[edit protocols mstp msti *msti-id* vlan (*vlan-id* | *vlan-name*) interface *interface-name*],  
[edit protocols rstp],  
[edit protocols rstp interface *interface-name*],  
[edit protocols stp],  
[edit protocols stp interface *interface-name*],  
[edit protocols vstp],  
[edit protocols vstp vlan *vlan-id* interface (all | *interface-name*)]

**Release Information**    Statement introduced in JUNOS Release 9.0 for EX-series switches.  
Statement updated in JUNOS Release 9.4 for EX-series switches to add VSTP support.

**Description**    Disable STP, MSTP, RSTP, or VSTP on the switch or on a specific interface.

**Required Privilege Level**    routing—To view this statement in the configuration.  
routing-control—To add this statement to the configuration.

**Related Topics**    ■ show spanning-tree bridge  
■ show spanning-tree interface  
■ Example: Configuring Network Regions for VLANs with MSTP on EX-series Switches  
■ Example: Configuring Faster Convergence and Improving Network Stability with RSTP on EX-series Switches  
■ Understanding MSTP for EX-series Switches  
■ Understanding STP for EX-series Switches  
■ Understanding VSTP for EX-series Switches

