

## e3-options

---

**Syntax** e3-options {  
    atm-encapsulation (direct | plcp);  
    bert-algorithm *algorithm*;  
    bert-error-rate *rate*;  
    bert-period *seconds*;  
    [Unresolved xref] *feet*;  
    compatibility-mode (digital-link | kentrox | larscom) <subrate *value*>;  
    fcs (16 | 32);  
    [Unresolved xref] (g.751 | g.832);  
    idle-cycle-flag *value*;  
    invert-data;  
    [Unresolved xref] (local | remote);  
    (payload-scrambler | no-payload-scrambler);  
    start-end-flag *value*;  
    (unframed | no-unframed);  
}

**Hierarchy Level** [edit interfaces *interface-name*]

**Release Information** Statement introduced before JUNOS Release 7.4.

**Description** Configure E3-specific physical interface properties.

For ATM1 interfaces, you can configure a subset of E3 options statements.

The statements are explained separately.

**Usage Guidelines** See [Unresolved xref] and [Unresolved xref].

**Required Privilege Level** interface—To view this statement in the configuration.  
interface-control—To add this statement to the configuration.

**Related Topics** atm-options

