

enable-service

Syntax	<code>enable-service <i>interface-name</i>;</code>
Hierarchy Level	[edit logical-systems <i>logical-system-name</i> services mobile-ip home-agent], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instances-name</i> services mobile-ip home-agent], [edit routing-instances <i>routing-instances-name</i> services mobile-ip home-agent], [edit services mobile-ip home-agent]
Release Information	Statement introduced in JUNOS Release 9.3. Support at the [edit logical-systems <i>logical-system-name</i> services mobile-ip home-agent], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instances-name</i> services mobile-ip home-agent], and [edit routing-instances <i>routing-instances-name</i> services mobile-ip home-agent] hierarchy levels added in JUNOS Release 9.5.
Description	Define the list of interfaces on which the home agent service can be enabled. The system accepts registration requests only if it is on one of these interfaces. Include the statement once for each interface to be enabled.
Options	<i>interface-name</i> —Interface on which the home agent can be enabled.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ Configuring Mobile IP■ Configuring the Mobile IP Home Agent

