

## family ethernet-switching

---

**Syntax** family ethernet-switching {  
    filter input *filter-name*;  
    filter output *filter-name*;  
    native-vlan-id *vlan-id*;  
    port-mode *mode*;  
    vlan {  
        members [ (all | *names* | *vlan-ids*) ];  
    }  
}

**Hierarchy Level** [edit interfaces *ge-chassis/slot/port* unit *logical-unit-number*]

**Release Information** Statement introduced in JUNOS Release 9.0 for EX-series switches.

**Description** Configure Ethernet switching protocol family information for the logical interface.  
  
The remaining statements are explained separately.

**Default** You must configure a logical interface to be able to use the physical device.

**Required Privilege Level** interface—To view this statement in the configuration.  
interface-control—To add this statement to the configuration.

**Related Topics**

- Configuring Gigabit Ethernet Interfaces (CLI Procedure)
- Configuring Gigabit Ethernet Interfaces (J-Web Procedure)
- EX-series Switches Interfaces Overview
- *JUNOS Software Network Interfaces Configuration Guide* at <http://www.juniper.net/techpubs/software/junos/junos95/index.html>

