

flow-tap

Syntax	flow-tap { interface <i>interface-name</i> ; }
Hierarchy Level	[edit services]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	Enable the flow-tap application on an interface.
Options	The remaining statements are explained separately.
Usage Guidelines	See [Unresolved xref] .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

