

forwarding-class

Syntax	forwarding-class <i>class-name</i> ;
Hierarchy Level	[edit services radius-flow-tap]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Specify forwarding class that is applied to mirrored packets sent to a mediation device.
Options	<i>class-name</i> —Name of the forwarding class.
Required Privilege Level	flow-tap—To view this statement in the configuration. flow-tap-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ Subscriber Secure Policy Overview■ Configuring Subscriber Secure Policy Mirroring Overview

