

## ietf-mode

---

<b>Syntax</b>	pre-ietf-mode
<b>Hierarchy Level</b>	[edit protocols ancp neighbor]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.5.
<b>Description</b>	Configure ANCP to run in a mode that is not backward compatible with Internet draft draft-ietf-ancp-protocol-00.txt, <i>Protocol for Access Node Control Mechanism in Broadband Networks</i> . Include this statement when pre-ietf mode has been configured globally for ANCP, but you want one or more neighbors to run ANCP in the default mode.
<b>Default</b>	By default, ANCP does not run in a backwards-compatible mode.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Configuring ANCP</li><li>■ Configuring ANCP Neighbors</li></ul>

