

ilmi

Syntax	ilmi;
Hierarchy Level	[edit interfaces <i>at-fpc/pic/port</i> atm-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Enable the routing platform to communicate with directly attached ATM switches and routers. The routing platform uses the VC 0.16 to communicate with the ATM switch or router. Once configured, you can display the IP address and port number of an ATM switch or router using the show interfaces <i>interface-name</i> <i>switch-id</i> command.
Usage Guidelines	See Configuring Communication with Directly Attached ATM Switches and Routers.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	show ilmi and show ilmi statistics commands in the <i>JUNOS Interfaces Command Reference</i>

