

incoming-called-number

Syntax	<code>incoming-called-number <i>number</i> <reject>;</code>
Hierarchy Level	[edit interfaces <i>br-pim</i> /0/ <i>port</i> isdn-options]
Release Information	Statement introduced on JUNOS Release 7.5.
Description	(J-series Services Routers) For interfaces configured for ISDN, screen incoming calls. If the incoming number is configured, the call is accepted. If the reject option is specified with the number, the call is rejected. If no numbers are configured, all calls are accepted.
Options	<p><i>number</i>—(Optional) Incoming caller number. Multiple numbers can be configured, up to a maximum of 30 entries. Only a precise match is a valid match. For example, the configured caller number 1-222-333-4444 or 222-333-4444 will match the incoming caller number 1-222-333-4444.</p> <p><i>reject</i>—(Optional) Rejects the incoming number.</p>
Usage Guidelines	See Configuring ISDN Physical Interface Properties.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS Services Interfaces Configuration Guide</i>

