

input-priority-map

Syntax	input-priority-map { ieee802.1p premium [<i>values</i>]; }
Hierarchy Level	[edit interfaces <i>interface-name</i> gigether-options ethernet-switch-profile ethernet-policer-profile]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	<p>For Gigabit Ethernet IQ and 10-Gigabit Ethernet interfaces only, define the input policer priority map to be applied to incoming frames on this interface.</p> <p>The statements are explained separately.</p>
Usage Guidelines	See Configuring Gigabit Ethernet Policers.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	output-priority-map

