

interface

Syntax	<code>interface sp-fpc/pic/port.logical-unit;</code>
Hierarchy Level	[edit services flow-tap]
Release Information	Statement introduced in JUNOS Release 8.1.
Description	Specify the AS PIC interface used with the flow-tap application. Any AS PIC available in the router can be assigned, and any logical interface on the AS PIC can be used.
Options	<i>interface-name</i> —Name of the DFC interface.
Usage Guidelines	See [Unresolved xref] .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

