

## line-protocol

---

<b>Syntax</b>	line-protocol <i>protocol</i> ;
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> serial-options]
<b>Release Information</b>	Statement introduced before JUNOS Release 7.4.
<b>Description</b>	For serial interfaces only, configure the line protocol.
<b>Options</b>	<i>protocol</i> —You can specify the one of the following line protocols: <ul style="list-style-type: none"><li>■ eia530—Line protocol EIA-530</li><li>■ v.35—Line protocol V.35</li><li>■ x.21—Line protocol X.21</li></ul>
<b>Usage Guidelines</b>	See Configuring the Serial Line Protocol.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

